6:09 Page 24

24 TROUBLESHOOTING

TROUBLESHOOTING

Before Calling for Service

If there is a problem with the product, check the following first before calling for service.

Problem	Possible Cause	Solutions
Air purifier does not turn on.	Power cord not plugged in.Incorrect power rating.	Plug cord securely into socket.Make sure outlet is rated for 115V.
Air output is weak, product makes a noise.	Pre-filter is clogged.Dust accumulation on the Puricare Main Filter.	Clean the pre-filter. Replace the Puricare Main Filter.
Air purification does not work well.	Indoor air quality is very bad. Dust has built up on the prefilter or Puricare Main Filter.	 Ventilate the room before using the air purifier. Clean the pre-filter or replace the Puricare Main Filter.
	• Usage area is too large.	Use the product in a smaller area or an area more protected from the influx of outside air.
	Nearby objects are blocking air circulation.	Remove nearby obstacles or move the product to a different location.
	The product is installed in a corner.	Move the product.
Strange odor coming from air outlet.	Installed in area with heavy smoke or odors.	Very heavy smoke or odors may degrade the performance of the filters. Ventilate the area before using the air purifier.
	Odor coming from deodorizing filter.	Replace the deodorizing filter.
There is an odor, but the Indicator lamp does not change.	Odor sensor may not respond to food odors as harmful.	Odor sensor may not respond to food odors as harmful, but odors are removed by the deodorizing filter.
Air quality shows red continuously.	 Air purifier may be unable to process amount of contamination in air. Water or oil sprayed near air purifier. 	 Try moving product to another room to clear the indicator. Do not spray water or oil near the air purifier.
Buttons do not work.	Lock function is enabled.	Press and hold Speed button and Indicator button for 3 seconds to disable the Lock function.



Problem Possible Cause Solutions • See instructions for cleaning sensor. Sensor may be dirty or blocked There has been no by foreign material. change in micro dust Air purifier may be in enclosed Indoor air quality may stay the same in concentration. an enclosed area. area. The fine dust Air purifier installed in area • Levels can remain high in areas where concentration with constant influx of outside there is a constant influx of outside air. value keeps air showing high. Air quality issue is from odor. Air quality light • The air quality indicator is an overall remains evaluation based on odor and dust. If red/orange while an odor is strong while PM levels are PM levels show low, the light may remain on low/normal. red/orange. The air purifier and EPA air • The EPA guide indicates an average The air quality quality values are measured value during a given time period and indicator differs differently. the air purifier's air quality indicator from the EPA measures and displays on a real-time guide. basis. • The deodorizing filter has Replace the filter. Filter life-expectancy become dirty. can vary based on usage environment. The air purifier is being used • Filter life can be greatly reduced if the instead of a vent hood while air purifier is used while cooking The filter produces cookina. strong-smelling or oily food. Do not odors. use the product in place of a vent hood. Ventilate the area during cooking to remove strong odors and oily splatter, then use the air purifier to eliminate any remaining odors.

