



OMS THD SKU # 1000 577 131

Model # TY315-1314



Thank you!

We appreciate the trust and confidence you have placed in Home Accents through the purchase of this 65in 160 Light Tinsel Nutcracker Soldier. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home decoration needs. Thank you for choosing Home Accents!

1-877-527-0313

HOMEACCENTSHOLIDAY.COM

Parts List		
Locater	Name	Qty.
A	Star	1
B	Pole Section	3
C	Head with Hat	1
D	Halves of Body	2
E	Sideburn	2
F	Arm	2
G	Leg	2
H	Visor	1

Hardware List		
Locater	Name	Qty.
I	Ground Stakes	4
J	Plastic Tie	15
K	Spare Fuse	2
L	Spare Bulb	4

ASSEMBLY INSTRUCTIONS

65in 160 Light Tinsel Nutcracker Soldier

USE AND CARE GUIDE

PLANNING ASSEMBLY

Carefully remove all the parts from the box and place them on a flat surface. Please note that many of the parts are connected by the lighting string that runs throughout the item. Remove the parts with care not to damage the lighting string or parts. Read the entire manual prior to assembly and identify all the parts included in the package against the parts list. If any parts are missing or damaged do not attempt assembly. Contact our customer service center or return the item to place of purchase with purchase receipt. Assembly of this product may require more than one person.

Pre-Operation

CAUTION: Grasp the plug to insert or remove from the power source. Do not unplug by pulling on cord.

CAUTION: The lighting string on this product is rated at 9.6Watts (0.08Amps). Do not overload. Do not connect to another lighting string, decorative outfit or other electrical products. Before you use or re-use this product, inspect it carefully. Discard or return to place of purchase with purchase receipt if the product has cuts, damage, frayed wire insulation on cords, cracks in the socket enclosures, loose connections or exposed copper wire.

Care and Cleaning

- Carefully remove the product from wherever it is placed. This helps to avoid any undue strain or stress on the product connections and wires. If the product is placed somewhere other than the ground it should be well secured and stable.
- Wipe the unit with a damp cloth and allow the unit to dry before storing.
- Store the product neatly in a cool, dry location protected from sunlight.

Guarantee


What is Covered

The product is intended for residential seasonal use for 90 days per year. This product is covered by a 90 days limited guarantee due to defects in material and workmanship. Return the product with purchase receipts to the location of purchase for refund within 90 days of purchase.


What is Not Covered

This warranty does not cover commercial use, normal wear and tear, products not used in accordance with directions provided on or with the product, burn out of bulbs or LEDs, batteries, products that have been subjected to unauthorized repair and/or modification and damage caused by shipping and improper handling, alterations, misuse or accidents. Questions, problems, missing parts? Before returning to the store, call Home Accents Holiday Customer Service 8 a.m.-6 p.m., EST, Monday-Friday

Diagram of Parts




Hardware



ASSEMBLY


1 Assembling the Body

Align the two Halves of Body (D) with each other and insert the connecting rods on one half into the holes on the other half then fasten them together with Plastic Tie (J) over the metal frames.




2 Assembling the Body and Legs

Insert the two connecting rods on each Leg (G) into holes at the bottom of the Body (D) and fasten them with Plastic Tie (J) over the metal frames.




3 Assembling the Arms

Insert the two connecting rods on each Arm (F) into the matching holes on the Body (D) and fasten with Plastic Ties (J).




4 Assembling the Head and the Sideburn

Insert the connecting rod on each Sideburn (E) into the matching holes on the sides of the Head with Hat (C). Insert the connecting rods on the bottom of the Head (C) into the matching holes on the top of Body (D) and fasten them with Plastic Tie (J).



5 Assembling the Visor and Pole Sections

Insert the connecting rods of the Visor (H) into the matching holes on the front of the Head with Hat (C). Connect the three Pole Sections (B) together and then attach the Star (A) to the top of the Pole. Insert the Pole into the left hand of the Soldier and allow the bottom of the Pole to reach the ground.



6 Assembling the Ground Stakes

Secure the Soldier Nutcracker to the ground with the Ground Stakes (I). Secure all parts with Plastic Ties over the metal frames as needed.

