




CARE AND MAINTENANCE

1. Cabinet should always be cleaned with a soft, damp cloth. All parts must be wiped dry after use or cleaning. A little mild liquid soap can be added to lukewarm water to remove stubborn stains.

⚠ Never use acetic or citric, scrubbing powder or solvent-base cleaners or other chemicals.

2. Mirrors should only be cleaned with a damp, soft cloth. Do not use commercial glass-cleaning agents. The mirror edges should be wiped dry only.



P.O. Box 26064 West Haven, CT 06516 USA
Toll Free Telephone Number: 800.527.6690
Toll Free Fax Number: 800.694.4837
www.whitehauscollection.com
info@whitehauscollection.com

TOOLS AND FITTINGS (not supplied with the product):


- Drill
- Screwdriver
- Leveling Ruler
- Phillips Head Screwdriver

NOTE: We reserve the right to change the features, packing and fittings of the product without notice.




INSTALLATION INSTRUCTIONS

NOTE: Contact an electrician for wiring of this product.




⚠ Prior to wiring installation, disconnect/unplug the defogger cable and remove cabinet door. Reconnect defogger cable and the cabinet door after installation is complete. You will hear a tone when the defogger is reconnected.

CABINET FEATURES DIAGRAM




WHKAL7055-I


1. Electrical Outlet




1. Verify required clearances. Measure and mark the cutout.




2. Cut away the drywall.




3. Frame out the wall cavity.



4. Secure the drywall to the framing.



5. With help, lift and hold the cabinet in the cutout.



6. Secure the cabinet to the framing.



WHLUN7055-IR

1. Electrical Outlet
2. Defogger Switch