



**JOMAX®
HOUSE WASH**

DESCRIPTION AND USES

Jomax® House Wash is an effective bleach-based exterior house wash designed to clean vinyl, wood, aluminum, masonry, stucco, brick and previously painted surfaces. It has excellent cleaning action with an advanced garden hose applicator which makes for an effective way to clean exterior surfaces. It is specially formulated to clean dirt, grime, mildew, chalk, soot, bird droppings and other stains. Jomax will not harm glass, bare aluminum or plants and shrubs and will not leave a film.

PERFORMANCE CHARACTERISTICS

- Effective bleach formula removes dirt, algae and mildew stains
- Convenient garden hose application reaches second story
- Can be used near plants and shrubs
- Great for cleaning vinyl, stucco, wood, brick, aluminum and painted surfaces

PRODUCTS

SKU	Description
60180	32 fluid ounces

PRODUCT APPLICATION

IMPORTANT

This product is for outdoor use only. Test on inconspicuous area before applying to ensure color safe results. Wear a long sleeve shirt, pants, eye protection and rubber gloves during use. Formula may stain clothes and shoes.

PREPARATION

Spray surrounding plants with water before and after application. Remove or cover all fabrics such as deck furniture, pads, umbrellas and awnings prior to application. Close all windows and doors. Use only on dry surfaces.

PRODUCT APPLICATION (cont.)

DIRECTIONS FOR USE

Spray surrounding plants with water. Shake well before spraying. Attach garden hose to nozzle with the valve in the OFF position. Turn on water to the hose. Turn nozzle to CLEAN and coat the area, applying liberally, working from the top down. Allow to work 5-10 minutes. **DO NOT ALLOW SOLUTION TO DRY.** Turn nozzle to RINSE and rinse the area well with water. If stains remain, a second application and light scrubbing may be required. Move to a new area and repeat the process. Spray surrounding plants with water after use. Turn valve to OFF position and turn water off to the hose. Move valve to RINSE position to release residual water pressure before detaching the nozzle from the garden hose. Turn valve to OFF for storage.

CAUTION! Avoid contact with eyes and skin. If eye contact occurs, flush with water for at least 15 minutes. If irritation persists, seek medical attention. Do not take internally. **KEEP OUT OF REACH OF CHILDREN.**

STORAGE AND DISPOSAL

Protect from freezing. Always keep the container tightly closed and store in a cool dry place at temperatures between 40-80°F (4-27°C). Dispose of container and unused contents in accordance with federal, state and local requirements.

**TECHNICAL DATA****JOMAX[®] HOUSE WASH****PHYSICAL PROPERTIES**

	HOUSE WASH
Composition	Sodium Hypochlorite, Water
Weight per Gallon	8.50 lbs.
Per Liter	1.02 kg
pH	NA
VOC	0 g/l
Practical Coverage	Cleans up to 1,500 square feet per quart
Shelf Life	5 years
Flash Point	>200°F (93°C)
Caution!	May cause eye irritation. May be harmful if swallowed. Avoid contact with eyes and prolonged contact with skin. Do not swallow. Use only with adequate ventilation. KEEP OUT OF REACH OF CHILDREN.
Safety Information	For additional information, see MSDS.

The technical data and suggestions for use contained herein are correct to the best of our knowledge, and offered in good faith. The statements of this literature do not constitute a warranty, express, or implied, as to the performance of these products. As conditions and use of our materials are beyond our control, we can guarantee these products only to conform to our standards of quality, and our liability, if any, will be limited to replacement of defective materials. All technical information is subject to change without notice.