


OMS THD SKU # 1002 334 164 Model # TY001-1729-4



Thank you!

We appreciate the trust and confidence you have placed in Home Accents through the purchase of this 36in Set of 3 Lighted LED Broom Pathway Stakes. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Accents!

1-877-527-0313 HOMEACCENTSHOLIDAY.COM

Parts List			
Locater	Name	Qty.	
А	Broom Pathway	3	
	Stake		

Hardware List		
Locater	Name	Qty.
В	Plastic Tie	5
С	Spare Fuse	2
D	Spare Bulb	2

ASSEMBLY INSTRUCTIONS

36in Set of 3 Lighted LED Broom Pathway Stakes

USE AND CARE GUIDE

PLANNING ASSEMBLY

Carefully remove all the parts from the box then place them on a flat surface. Many of the parts are connected by the lighting string that runs throughout the item. Use caution not to pull excessively or force parts loose as this could damage the item and the lighting string. Read the entire manual prior to assembly to identify all the parts included in the package against the parts list. If any parts are missing or damaged do not attempt assembly. Contact our customer service center.

*Assembly of this product may take more than one person.

Pre-Operation

CAUTION: Grasp the plug to insert or remove from the power source. Do not unplug by pulling on cord.

CAUTION: The lighting string on this product is rated at 2.4 Watts (0.02Amps). Do not overload. Do not connect to another lighting string, decorative outfit or other electrical products. Before you use or re-use this product inspect it carefully. Discard or return to place of purchase with purchase receipt if the product has cuts, damage, frayed wire insulation on cords, cracks in the socket enclosures, loose connections or exposed copper wire.

Care and Cleaning

- a. Carefully remove the product from wherever it is placed. This helps to avoid any undue strain or stress on the product connections and wires. If the product is placed somewhere other than the ground it should be well secured and stable.
- b. Wipe the unit with a damp cloth and allow the unit to dry before storing.
- c. Store the product neatly in a cool, dry location protected from sunlight.

Guarantee


What is Covered

The product is intended for residential seasonal use for 90 days per year. This product is covered by a 90 days limited guarantee due to defects in material and workmanship. Return the product with purchase receipt to the location of purchase for refund within 90 days of purchase.

What is Not Covered

This warranty does not cover commercial use, normal wear and tear, products not used in accordance with directions provided on or with the product, burn out of bulbs or LEDS, batteries, products that have been subjected to unauthorized repair and/or modification and damage caused by shipping and improper handling, alterations, misuse or accidents. Questions, problems, missing parts? Before returning to the store, call Home Accents Holiday Customer Service 8 a.m.-6 p.m., EST, Monday-Friday


Diagram of Parts



ASSEMBLY

1 Preparing the Broom Pathway Stakes

The Broom Pathway Stakes come Pre-Assembled with the Lighting Sting. Before you install the Stakes into the ground have a plan for your desired location to make sure you can run the proper power and the area is clear of debris, other electrical wires and/or landscaping plumbing or structure. Note: The Lighting String has end-to-end connectors so multiple sets can be connected.



2 Installing the Broom Pathway Stake to the Ground

The Stake has two (2) prongs at the bottom end. Once you have your desired install location place the Stake over the location and gently press down on top of the 2-prong Stake with one hand, while the other hand holds the Stake Pole at the middle of the stake, until the Stake penetrates the ground. Do not attempt to install holding the decorative "Broom" portion of the Stake.

NOTE: If ground is hard and stake is difficult to install, make a crosscut in the ground using a shovel and moisten with water.

