




Item # 1000 117 123  
Model # X1250B-CPY

# USE AND CARE GUIDE

---

## HARBOR GAZEBO REPLACEMENT CANOPY



Questions, problems, missing parts? Before returning to the store,  
call Hampton Bay Customer Service.  
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

**1-855-HD-HAMPTON**

**HAMPTONBAY.COM**

---

### **THANK YOU**

*We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this harbor canopy. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!*

# Table of Contents

Table of Contents.....	2	Pre-Assembly .....	2
Safety Information .....	2	Planning Assembly .....	2
Safety Warnings .....	2	Package Contents .....	3
Warranty .....	2	Assembly .....	4
What is Covered .....	2	Care and Cleaning .....	6
What is Not Covered .....	2		

# Safety Information

## SAFETY WARNINGS



**WARNING:** Keep all flame and heat sources away from this gazebo fabric.



**WARNING:** This application of any foreign substance to the gazebo fabric may render the flame resistant properties ineffective.



**WARNING:** This gazebo is made with fabric that meets CPAI - 84 specifications for flame resistance. It is not fire proof. The fabric will burn if left continuous contact with any flame source.

# Warranty

## 1 YEAR FABRIC WARRANTY

### WHAT IS COVERED

We warrant the fabric to be free of manufacturing defects to the original purchaser for one year.

### WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit [www.HamptonBay.com](http://www.HamptonBay.com)

# Pre-Assembly

## PLANNING ASSEMBLY

Read all instructions before assembly.



To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



**NOTE:** More than one person may be required to complete the assembly of this product.

# Pre-Assembly (continued)

## PACKAGE CONTENTS




Part	Description	Quantity
N	Small fabric cover	1
O	Large fabric cover	1

# Assembly

## 1 Replacing the large fabric cover

- Place the large fabric cover (0) on top of the assembled frame.
- Fully extend the large fabric cover (0) to the end of the spokes.




## Assembly (continued)

### 2 Reattaching the canopy spokes and hub (not included)

- Insert the upper canopy spokes (I) into the upper canopy hub (J).
- Then insert the upper canopy spokes (I) into the top tubes (G).




**NOTE:** The upper canopy spokes (I), upper canopy hub (J), and top tubes (G) are not included with the replacement canopy.



## Assembly (continued)

### 3 Replacing the small fabric cover

- Place the small fabric cover (N) on the upper canopy spokes, and fully extend the small fabric cover to the ends of the upper canopy spokes.



## Care and Cleaning

- For best results, clean the fabric with a damp cloth, and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- Do not clean with abrasive materials, bleach, or solvents.
- Store the canopy in a dry, sheltered place when not in use.
- Keep the canopy away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.



Questions, problems, missing parts? Before returning to the store,  
call Hampton Bay Customer Service  
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

**1-855-HD-HAMPTON**

**HAMPTONBAY.COM**

Retain this manual for future use.