

Egg Chair FHEC100 Part List



- (4) Legs
- (4) Rubber feet
- (1) Lower Bow with feet connectors
- (1) Upper Bow
- (1) Top Pin
- (1) Lower Pin
- (6) Nuts and Bolts
- (1) Seat Spring
- (4) Catch Pins
- (1) Main Chair C-Frame
- (1) Bottom Cushion
- (1) Leisure Cushion
- (1) Allen Wrench

Egg Chair FHEC100 Assembly Instructions



1. Open the package and unwrap the four short legs and put rubber feet on each of the four legs



6. Attach seat spring to swivel pin



2. Bolt the four legs to the X-frame base of the Egg Chair Stand



7. Put the shorter of the two swivel pins through the top of the chair and through the grommet



3. Put nuts and bolts in middle of C frame stand



8. Then attach to spring on stand





4. Open egg chair frame completely and put the four catch pins in place

Make sure the flat tops are on the inside of the chair so they do not poke through the fabric or through the seat



9. Make sure all fasteners are tight in the seat frame is straight I just your pillows the way you like put in a good level location and enjoy your egg chair thank you for your business



5. Put the longer of the two swivel pins in the top of the C frame stand

