



Model: GP1059291

Compatible with the following KOHLER models:

| | | | | |
|-----------|--------|--------|-----------|---------|
| K-3496 | K-3713 | K-3978 | K-4634 | K-11813 |
| K-3496-HE | K-3754 | K-3979 | K-4634-HE | K-11821 |
| K-3497 | K-3755 | K-3986 | K-4641 | K-11823 |
| K-3509 | K-3810 | K-3997 | K-4642 | K-11844 |
| K-3511 | K-3811 | K-3998 | K-4835 | K-11968 |
| K-3515 | K-3812 | K-3999 | K-4841 | K-12697 |
| K-3517 | K-3813 | K-4166 | K-4899 | K-12698 |
| K-3526 | K-3816 | K-4167 | K-5380 | K-12767 |
| K-3532 | K-3817 | K-4383 | K-6925 | K-14231 |
| K-3533 | K-3818 | K-4418 | K-10491 | K-14233 |
| K-3542 | K-3819 | K-4421 | K-10492 | K-14345 |
| K-3548 | K-3825 | K-4431 | K-10493 | K-14346 |
| K-3551 | K-3827 | K-4433 | K-10494 | K-14509 |
| K-3574 | K-3828 | K-4434 | K-10495 | K-14797 |
| K-3575 | K-3837 | K-4436 | K-11451 | K-14799 |
| K-3576 | K-3851 | K-4436 | K-11452 | K-14824 |
| K-3577 | K-3887 | K-4437 | K-11453 | K-15410 |
| K-3589 | K-3888 | K-4438 | K-11456 | K-98977 |
| K-3609 | K-3889 | K-4446 | K-11460 | K-98992 |
| K-3611 | K-3933 | K-4467 | K-11461 | K-98993 |
| K-3615 | K-3940 | K-4468 | K-11465 | K-98994 |
| K-3639 | K-3946 | K-4469 | K-11471 | |
| K-3648 | K-3947 | K-4473 | K-11473 | |
| K-3667 | K-3948 | K-4474 | K-11492 | |
| K-3668 | K-3949 | K-4485 | K-11497 | |
| K-3669 | K-3950 | K-4493 | K-11498 | |
| K-3678 | K-3977 | K-4632 | K-11499 | |