


Wood Burning 24" & 30" Fire Ring With Cooking Rack And Hinge Anchor



MODEL 24" & 30" FIRE RING WITH COOKING RACK

INSTRUCTIONS

NOTE: READ INSTRUCTION BEFORE USING YOUR FIRE RING, USE EXTREME CAUTION AT ALL TIMES WHILE IN USE!

SAFETY NOTICE: DO NOT INSTALL IN OR ON RECREATIONAL VEHICLES AND/OR BOATS, FOR YOUR SAFETY.

WARNING: FAILURE TO FOLLOW THE DANGERS, WARNING AND CAUTIONS CONTAINED IN THIS OWNERS MANUAL MAY RESULT IN SERIOUS BODILY INJURY OR DAMAGE TO PROPERTY.

WARNING! CARBON MONOXIDE HAZARD! BURNING WOOD OR CHARCOAL PRODUCES CARBON MONOXIDE, WHICH HAS NO ODOR AND CAN KILL YOU IF BURNED IN ENCLOSED AREAS. NEVER BURN WOOD OR CHARCOAL INSIDE HOMES, VEHICLES, TENTS OR ANY OTHER ENCLOSED AREAS.

BUCK STOVE FIRE RING WITH COOKING RACK

- ◆ When selecting a location for your Buck Stove 24" or 30" Fire Ring it is important to consider the required clearances to all combustibles.
- ◆ Locate the Buck Stove Fire Ring with a **minimum of (4'-fourfoot)** must be maintained between your Fire Pit and any combustible materials with **NO COMBUSTIBLES OVER HEAD** while in operation. Follow local codes and specific safety instruction for your area.

Installation:

After removing the Fire Ring from the packing, place the Fire Ring in an area that meets the required clearances to all combustibles. Place the Fire Ring on a noncombustible surface, dirt with no grass or combustible materials in the area of burning surface.


•**Anchor Stake Installation:** Place the Fire Ring in location and securely anchor Fire Ring in place using the anchors provided. Place the three anchors in the three anchor holders inside fire ring See Next Page (Figure 1). Hammer the anchors into the ground till they are firm against the anchor holders.

•**Hinge Anchor Installation:** Securely anchor Fire Ring in place using the Z anchors provided. Place the Fire Ring in location and dig a hole deep enough for the Z anchors. Place Z anchors into the anchor hinges from the inside out, See Next Page (Figure 2) and cement Z anchors in place.

Cooking Rack:

The Buck Stove Fire Ring has an adjustable cooking rack. Adjust the cooking rack by tightening or loosening the T-LOCKING BOLT on the cooking rack. See Picture Below. This is also used for removing the cooking rack for cleaning and storage. NOTE: When cooking on cooking rack, always use tinfoil, pots or pans on cooking rack.

- ◆ **NOTE:**The manufacturer recommends that for maximum performance burn natural seasoned hard wood. Lay several pieces of dry kindling on top of newspaper in the Fire Ring. Place several pieces of natural seasoned hard wood or hickory wood on kindling. Light newspaper. Don't leave fire unattended at this point. NOTE: The cooking rack is HOT at this time and should not be touched without adequate protection. After embers and a coal bed have been established, load Fire Ring with seasoned natural hard wood as desired for cooking. Your Buck Stove Fire Ring with cooking Rack is ready for use..



NOTE: Always keep safety in mind when disposing hot ashes. Pour water on them until out. Dig hole and bury ashes, transport ashes using metal container with lid.