

Parts that need cleaning:

Shower Head, Nut, Water Flow Regulator, Washer

Cleaning Instructions

To maintain proper working condition, cleaning is required when mineral deposits appear on jet tips. Clean flexible nozzles by rubbing with a finger or a soft bristled toothbrush, or soak in 50% white vinegar/50% water solution. DO NOT use harsh chemicals, heavy-duty cleaners or abrasives. This may damage parts or finish and may void warranty.