


CARE INSTRUCTIONS


Thank you for choosing northbeam™ SIX TIER WOODEN SHOE DRESSER. With little care and maintenance, the northbeam™ SIX TIER WOODEN SHOE DRESSER will provide you with comfort and enjoyment for many years to come!


- To clean panels, use clean water on a damp cloth.
- When assembling northbeam™ SIX TIER WOODEN SHOE DRESSER, please handle all the panels and/or hardware with care to avoid any possibilities of damages and/or injuries.





north beam "


PARTS

















5



6



north beam "





Please check contents before assembly. If any items are missing or damaged, do not take the unit back to the store. Call (775) 629-5029 or email: service@merryproducts.com for customer service and we will save you time by correcting any problems directly for you.