

### TROUBLESHOOTING:

	Possible Cause	Corrective Action
Light will not turn on.	<ol style="list-style-type: none"> <li>1. Power is off.</li> <li>2. Faulty switch.</li> <li>3. Faulty wire connection.</li> </ol>	<ol style="list-style-type: none"> <li>1. Make sure power supply is on.</li> <li>2. Test or replace switch.</li> <li>3. Check wiring.</li> </ol>
Fuse blows or circuit breaker trips when light is turned on.	<ol style="list-style-type: none"> <li>1. Crossed wires or power wire is grounding out.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check wire connections.</li> </ol>

### PRODUCT MAINTENANCE:

1. To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the surface of the fixture.
2. To clean the inside of the fixture, first disconnect power to the fixture by turning off the circuit breaker or by removing the fuse at the fuse box. Next, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the interior surface of the fixture.
3. Do not use any cleaners with chemicals, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.



### LIMITED WARRANTY

The manufacturer warrants this lighting fixture to be free from defects in materials and workmanship for a period of five (5) years (except bulb) from date of purchase. This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If this product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, set-up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, or faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear. The manufacturer does not warrant and specially disclaims any warranty, whether expressed or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including but not limited to any labor/expense costs involved in the replacement or repair of said product.

# 4 Light Vanity with Glass Globes

## Models 7544 - 7545

# INSTALLATION MANUAL




# Installation

**⚠ DANGER:** Before installation, turn off the main power at the circuit breaker.


**⚠ WARNING:** Installation must be performed by a qualified licensed electrician.

## TOOLS REQUIRED FOR INSTALLATION AND ASSEMBLY (not included):




## 1 Install the mounting bracket

A. Pull the power supply wires out from the outlet box. Thread the Fixture Mounting Screws (B) through the Mounting Bracket (A) into the junction box, as shown.



## 2 Connecting the wires

A. Connect the white supply wire to the white fixture wire.  
 B. Connect the black supply wire to the black fixture wire.  
 C. Connect the ground supply wire to the ground fixture wire.  
 D. Use wire nuts to secure all connections.



## 3 Installing the wall fixture

A. Carefully tuck the fixture wires into the junction box.  
 B. Install the fixture threaded rods through the backplate and tighten the Fixture Mounting Decorative Nuts so that the backplate is secured flush against the wall.  
 C. Install the Glass Globe with the threaded nuts. Do not over tighten. Install the light bulbs.

