



Wood Pergola Safety and Care Instructions

Instructions

- Wash pergola with garden hose or mild detergent solution and soft cloth. DO NOT use stiff or abrasive cleaner that could damage pergola. DO NOT use cleaner such as bleach or ammonia.
- Hot items, such as blowtorches, must not be used in or near the pergola.
- Heavy articles should not rest on the posts as this may cause permanent damage.

Note: Our Pergola's are shipped as an unfinished product. If exposed to the elements, the Western Red Cedar lumber will weather to a silvery-gray color.

If you prefer to keep the cedar lumber looking closer to the original color, we suggest that you treat the wood with a good oil based wood stain. You may also wish to paint your new Pergola rather than stain it. In both cases we recommend that you consult with a paint and stain dealer in your area.