


EXPLODED VIEW



PARTS LIST

ITEM NO.	PART NO.	DESCRIPTION	QTY
1	34106647	right handle	1
2	34105647	left handle	1
3	34107647	switch button	1
4	32201647	spring	3
5	32201459	screw	18
6	34109453-1	button	1
7	32211365	screw	1
8	3290675	washer	3
9	34104647	decoration ring	1
10	34102647	button	1
11	36301454-1	switch	1
12	34108647	right housing	1
13	34103647	left housing	1
14	3220203	screw	2
15	34101647	guard shield	1
16	3290305	washer	2
17	32201162	screw	2
18	31103453-1	assistant handle assembly	1
19	332203166	handle nut	1
20	34104978	housing battery socket	1
21	31110647	motor assembly	1
22	34113453A	blade cover	1



TOLL-FREE HELPLINE: 1-888-90WORKS (888.909.6757)

Rev: 00 (01-17-14)



Printed in China on 100% Recycled Paper