

TENAX[®]

SOLUTIONS ALL AROUND YOU

GUARDIAN VISUAL BARRIER

BARRERA VISUAL GUARDIAN / FILET DE SIGNALISATION À HAUTE VISIBILITÉ



RECOMMENDED USES

Visual barrier for use on construction sites, parking lots and warehouses.

Spanish: Barrera visual para uso alrededor de los sitios de construcción, estacionamientos y almacenes.

French: Clôture de sécurité pour une utilisation autour de zones dangereuses, de trafic ou dans des zones piétonnes.

Visual barrier for use around hazard, traffic or pedestrian areas.

Spanish: Barrera visual para uso alrededor de áreas de riesgo, tráfico o peatonales.

French: Barrière visuelle pour une utilisation autour des zones danger, la circulation et piétons.

Reusable visual barrier for property delineation or home construction.

Spanish: Barrera visual reutilizable para la delimitación de propiedad o construcción de viviendas.

French: Barrière visuelle réutilisable pour la délimitation de la propriété ou la construction de la maison.



4-FT x 100-FT

1.21-M x 30.48-M

MESH SIZE 1.75-IN x 1.75-IN

Spanish: tamaño de malla 4.44-CM x 4.44-CM / French: maillage 4.44-CM x 4.44-CM

ORANGE / NARANJA / ORANGE

Scan the code for instructions.



Spanish: Lea el código para obtener instrucciones.

French: Scannez le code pour les instructions.



YOU MAY NEED

posts
mallet
fence ties
wood slat



INSTRUCTIONS

(1) Your Tenax fencing can be installed using metal or fiberglass posts. (2) If installing a 4 foot fence, use a post that is 5-6 feet tall. (3) Drive at least 1 foot of post into the ground using a mallet. (4) One post should be placed every 8-10 feet. (5) Fence should be stretched across posts and attached using 3 fence ties securing the fence at the top, middle, and bottom of each post. (6) To connect fence sections, overlap two ends and weave a wood slat through the overlapped strands, secure the slat with fence ties. For additional strength secure the joined area to a post.



TENAX CORPORATION

4800 E. Monument Street / Baltimore, MD 21205

phone 410-522-7000 / fax 410-522-3190 / www.tenaxus.com