




Item # 1002 557 900
Model #186-411-ALC

USE AND CARE GUIDE

Oak Cliff Armless Lounge Chair



Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8.00 a.m. - 7.00 p.m. EST, Monday - Friday,
9.00 a.m. - 6.00 p.m. EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this armless lounge chair. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs.

Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents.....	2	Pre-Assembly.....	3
Safety Information.....	2	Planning Assembly.....	3
Warranty.....	2	Hardware Included.....	3
2 Year Frame and Fabric Limited Warranty.....	2	Package Contents.....	4
What Is Covered	2	Assembly	5
What Is Not Covered	2		
Care Instructions.....	2		

Safety Information



DANGER: Please keep children out of the assembly area during assembly.



CAUTION: Use the chairs on flat ground only.



IMPORTANT: Please check the tightness of the bolts periodically.

Warranty

2 YEAR FRAME AND FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame and fabric to be free of manufacturing defects to the original purchaser for two years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Care Instructions

Before using, wipe with a clean, dry cloth. Do not use bleach or solvents. Treat frame with one step liquid wax for maximum protection against UV light and salty, damp air. When not in use, store furniture in a cool, dry place. If your set includes cushions, they may be cleaned by hand with a mild solution of soap and water. Rinse cushion thoroughly and allow to drip dry. Do not machine wash or tumble dry, as cushions may shrink. Do not use bleach or solvents on fabrics.

You may contact our customer service department with any questions by phone at 1-855-HD-HAMPTON or visit www.hamptonbay.com.

Pre-Assembly

PLANNING ASSEMBLY

It will take two people about 10 minutes to complete the assembly process.

HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.

HARDWARE (Assembling the armless chair only.)



Part	Description	Quantity
AA	Bolt cap (M6)	4
BB	Bolt (M6x20)	4
CC	Washer (M6)	4
DD	Hex wrench	1

HARDWARE (To be used for securing the armless chair onto other chairs only.)




Part	Description	Quantity
AA	Bolt cap (M6)	8
BB	Bolt (M6x20)	4
CC	Washer (M6)	12
EE	Bolt (M6x45)	4
FF	Spanner	1
GG	Nut (M6)	4
HH	Nut cap (M6)	4
II	Washer plate	2



NOTE: Hardware quantity may be more than what you need.
This depends on what you order.

Pre-Assembly (continued)


PACKAGE CONTENTS



Part	Description	Quantity
A	Back panel	1
B	Seat panel	1
C	Back cushion	1
D	Seat cushion	1


Assembly

1 Attaching the back panel



- Place the seat panel (B) on its side on a flat, smooth surface.
- Attach the back back to the seat panel with washers (CC) and bolts (BB) using hex wrench (DD).
- Fully tighten all the bolts and cover them with bolt caps (AA).


2 Placing cushions



- Turn the lounge chair upright.
- Level the lounge chair with foot glides at the bottom of front legs.
- Place cushions (C) and (D) on the chair. Secure the seat cushion (D) on the frame with hook and loop straps.


Assembly

1 If you bought 2 armless chairs and 1 set of 3 piece sectional set



- Secure the back panels of the armless chairs (1) to those of the love seats (2) and corner sectional chair (3) with washer plates (II), washers (CC) and bolts (BB) using hex wrench (DD).
- Secure the seat panels of the armless chair (1) to those of the love seats (2) and corner sectional chair (3) with washers (CC), bolts (EE) and nuts (GG) using hex wrench (DD) and spanner (FF).
- Fully tighten all the bolts and nuts . Cover them with bolt caps (AA) and nut caps (HH) respectively.

2 If you bought 2 armless chairs only



- Use washer plate (II), washers (CC) and bolts (BB) to secure the back panels of both armless chairs (1) to each other.
- Use washers (CC), bolts (EE) and nuts (GG) to secure the seat panels of both armless chairs to each other.
- Fully tighten all the bolts and nuts . Cover them with bolt caps (AA) and nut caps (HH) respectively.



Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8.00 a.m. - 7.00 p.m. EST, Monday - Friday,
9.00 a.m. - 6.00 p.m. EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manual for future use.