




Replacement Parts List

Gatsby | 4 in. Centerset 1-Handle Bathroom Faucet in Brushed Nickel

| MODEL | SKU # | FINISH |
|---------------|-----------|----------------|
| HD66289W-6104 | 304685510 | Brushed Nickel |



Many replacement parts can be purchased online or at your local store. Please use the table below to identify the part SKU number needed, go to HOMEDEPOT.COM, and check for online and store availability. If you can't find the part you are looking for, please call 1-855-HD-GLACIER.

| Part | Description | Part # | Internet SKU # | Store SKU # |
|------|-------------------|-----------|----------------|-------------|
| 1 | Handle assembly | RP1360304 | | |
| 2 | Cap | RP8013204 | | |
| 3 | Bonnet | RP70343 | | |
| 4 | Cartridge & Screw | RP20105 | | |
| 5 | Deck plate | RP8047304 | | |
| 6 | Gasket | RP80474 | | |
| 7 | Rubber washer | RP64176 | | |

| Part | Description | Part # | Internet SKU # | Store SKU # |
|------|------------------------------|-----------|----------------|-------------|
| 8 | Metal washer | RP64177 | | |
| 9 | Nut | RP56081 | | |
| 10 | Screen filter | RP70072 | | |
| 11 | ClickInstall™ drain assembly | RP4022804 | | |
| 12 | Lift rod | RP4028804 | | |