


88 5555 80 Arm Chair

IMPORTANT NOTE

Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damages occurring to the wood parts.

We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.


Home
Styles



Part List



A.
Back
1 pc.



B.
Seat
1 pc.



C.
Side Frame
1 pc.



D.
Side Frame
1 pc.

Hardware List



Key Wrench
(small)
1 pc.



Bolt (small)
4 pcs.(+1 extra)



Spring
Washer (small)
4 pcs.(+1 extra)



Flat
Washer (small)
4 pcs.(+1 extra)



Nut (small)
4 pcs.(+1 extra)



Nut Cap (small)
4 pcs.(+1 extra)



Key Wrench
(large)
1 pc.



Bolt (large)
4 pcs.(+1 extra)



Spring
Washer (large)
4 pcs.(+1 extra)



Flat
Washer (large)
4 pcs.(+1 extra)



Nut (large)
4 pcs.(+1 extra)



Nut Cap (large)
4 pcs.(+1 extra)

IMPORTANT


* Do not tighten up all the screws until each part is properly assembled.

* After assembly, item must be level to work properly. Use the included adjustable levelers to level.

STEP 1

Attach Side Frame (C) and (D) to Seat (B) with Bolts, Spring Washers, Flat Washers and Nuts.

Tighten all Bolts with Key Wrench.
Cover all Nuts with Nut Caps.




Flat Washer (large)
Spring Washer (large)
Nut (large)
Nut Cap (large)

STEP 2

Attach Back (A) to unit with Bolts, Spring Washers, Flat Washers and Nuts.

Tighten all Bolts with Key Wrench.
Cover all Nuts with Nut Caps.

Nut Cap (small)
Nut (small)
Spring Washer (small)
Flat Washer (small)



Please keep the Key Wrench as you may need to retighten the Bolts in the future.

Tools required for assembly : **Phillips** screwdriver

Home Styles Consumer Assistance Line 888-680-7460 and 877-831-0319

servicedesk@homestyles-furniture.com

Revised 17Mar2011