



# How to Measure (Motor Operated with Remote)

**Please note:** The fabric width will be approximately 2" narrower than the Valance (overall, not per side).  
Our outdoor shades have a 96" fabric drop (not customizable, you do not have to roll your shade down completely).

## Inside Mount



## Outside Mount



**1** Measure your frame width in at least two (2) places. Use the narrowest dimension as your frame width.

**2** Subtract 0.5" to determine the Valance width you will order.

### Measuring Tips

- Frame Width - 0.5" = Valance width to order

**1** Measure the window width.

**2** If you want the fabric to completely cover your window, we recommend you order your fabric to be 4" wider (2" per side) than your window width. This will prevent light from entering on the sides of your fabric.

### Measuring Tips

- Window width + 4.0" = Fabric width to order
- Fabric width + 2" = Valance width to order