

Repair Parts List

Lower gun body frame 1

Trigger 1

Trigger insert 1

Pin 1

Locking lever 1

body 1

Washer 2

Zinc pipe 1

Fnipple 1

Screw 6

Upper gun body frame 1

Protector 1

Back ring 1

O-ring viton 1

Washer 1

Spring 1

Pin 1

O-ring 1

Seat 1

Ball 1

Pressure spring 1

O-ring 1

Spring plug 1