




Replacement Parts List

Upson Pull-Down Kitchen Faucet

MODEL	SKU #	FINISH
HD67553-014405	305764866	Matte Gold



Many replacement parts can be purchased online or at your local store. Please use the table below to identify the part SKU number needed, go to HOMEDEPOT.COM, and check for online and store availability. If you can't find the part you are looking for, please call 1-855-HD-GLACIER.

Part	Description	Part #	Internet SKU #	Store SKU #	Part	Description	Part #	Internet SKU #	Store SKU #
1	Spray head and Hose	RP382424405			14	Mounting nut	RP56109		
2	O-ring	RP60006			15	Block	RP70421		
3	Wearable ring	RP64092			16	O-ring	RP60002		
4	Cartridge	RP20005	207093806		17	Quick connect assembly	RP70501		
5	Bonnet nut	RP70533			18	O-ring	RP60089		
6	Cap	RP800284405			19	Weight	RP70525		
7	Screw	RP50015			20	Weight clip	RP70609		
8	Handle	RP133934405			21	Plastic washer	RP64131		
9	Set screw	RP50002			22	Metal washer	RP64146	301158339	
10	Flange	RP803334405			23	Nut & Screw	RP56113		
11	Escutcheon	RP803324405							
12	Gasket	RP80560							
13	Bolt	RP50071							