

HOME DECORATORS COLLECTION

ITEM # 1002 555 714
1002 555 913

MODEL # FBA00002GF
FBA00002GL


Naples Chaise

Use and Care Guide

Operation

1 Using Naples Chaise

- Always place the Naples Chaise on a hard, level surface.
- Raise or lower the backrest of the chaise using the support bar on the chaise back.



Care and Cleaning

- For best results, clean the frame with a damp cloth, and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- Do not clean with abrasive materials, bleach or solvents.
- Store the chaise in a dry, sheltered place when not in use.
- Keep the chaise away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

Warranty

2 YEAR FRAME AND 2 YEAR LIMITED FABRIC WARRANTY

WHAT IS COVERED

We warrant the frame and the fabric to be free of manufacturing defects to the original purchaser for two years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center.

This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For questions or concerns about this product contact the Customer Service Team 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday at 1-800-986-3460 or visit www.Homedepot.com/homedecorators.