

Counterclockwise turn to unlock



Extend into place



Clockwise turn to lock



Counterclockwise twist grip to tighten



