

To find how many boxes you need for your room,
 simply cross reference the room width with the room length using the chart below

		Room length up to												
		11' 9.7"	15' 8.9"	19' 8.2"	23' 7.4"	27' 6.7"	31' 5.9"	35' 5.1"	39' 4.4"	43' 3.6"	47' 2.9"	51' 2.7"	55' 1.4"	59' 0.6"
Room width up to	2' 5.1"	1	2	2	2	3	3	3	4	4	4	5	5	5
	4' 11.8"	2	3	4	4	5	6	6	7	8	8	9	10	10
	7' 6.5"	3	4	5	6	7	8	9	10	11	12	13	14	15
	10' 1.2"	4	6	7	8	10	11	12	14	15	16	18	19	20
	12' 7.9"	5	7	9	10	12	14	15	17	19	20	22	24	25
	15' 2.6"	6	8	10	12	14	16	18	20	22	24	26	28	30
	17' 9.3"	7	10	12	14	17	19	21	24	26	28	31	33	35
	20' 4"	8	11	14	16	19	22	24	27	30	32	35	38	40
	22' 10.8"	9	12	15	18	21	24	27	30	33	36	39	42	45
	25' 5.5"	10	14	17	20	24	27	30	34	37	40	44	47	50
	28' 0.2"	11	15	19	22	26	30	33	37	41	44	48	52	55
	30' 6.9"	12	16	20	24	28	32	36	40	44	48	52	56	60
	33' 1.6"	13	18	22	26	31	35	39	44	48	52	57	61	65
	35' 8.3"	14	19	24	28	33	38	42	47	52	56	61	66	70
	38' 3"	15	20	25	30	35	40	45	50	55	60	65	70	75
	40' 9.7"	16	22	27	32	38	43	48	54	59	64	70	75	80
43' 4.4"	17	23	29	34	40	46	51	57	63	68	74	80	85	
45' 11.1"	18	24	30	36	42	48	54	60	66	72	78	84	90	
48' 5.8"	19	26	32	38	45	51	57	64	70	76	83	89	95	