

Auger to Post Hole Digger Assembly

Attach the auger to the output shaft on the bottom of the gear box using 1/2 in. hex cap screws ①, 1/2 in. lock washers ② and 1/2 in. hex nuts ③ provided.

