



Tools Required for Installation:

(These are the tools that are generally required for assembly of our outdoor products. These tools are not included with the outdoor product purchase.)



(Level 24")



(Square)



(Cordless Drill or Electric Drill)




(Drill Attachments: Phillips Head & Socket Driver)



(Rubber Mallet - Optional)



(Tape Measure)



(3/8" Drive Ratchet, 1/2" STD Sockets 1/2" Deep Sockets)



(7/16" Drill Bit)



(Claw Hammer)



(Open End Wrenches 1/2")



(An Adult w/ an Adult Helper)



(Ladder)



(Phillips Screw Driver)