

Use and Care Guide


24 in. Septic Tank Riser Cover




Item # 1002 711 123
Model # THD1069



TOOLS REQUIRED




Drill with 3/16 in. drill bit



#3 Square Driver

PACKAGE CONTENTS



A - Riser Cover x1




B - Square drive screws x4

Installation

1 PREPARING FOR INSTALLATION

- This 24 in. septic tank riser cover (A) will fit most 24 in. installed risers. Test fit the riser cover (A) to ensure it is correct for your riser.
- Clean the sealing surface of your riser.
- Remove the hardware pack containing the four square-drive screws (B) from the back of the riser cover (A).




2 INSTALLING THE RISER COVER

- Place the riser cover (A) on your riser. Ensure the rubber seal is making a seal with the top of your riser.
- Using the four screw holes in the riser cover (A) as a guide, drill four 3/16 in. holes through your riser.



NOTE: Some risers may require the use of holes other than the molded screw holes in the riser cover. For these risers, use the two additional drill points molded on the top of the cover.

- Install the screws (B) with a #3 square driver.
- For access to your riser, remove the screws (B) and cover (A), then reinstall.



Safety Information



WARNING: Failure to properly secure the riser cover will create a serious safety risk. Follow these installation instructions carefully.

Warranty

This product is warranted to the original consumer purchaser to be free from defects in material and workmanship for a period of one year from the date of purchase. For additional details and questions, please contact Everbilt Customer Service at 1-877-297-6069.



HOMEDEPOT.com

Please contact 1-877-297-6069 for further assistance.