



To Replace Filters:

These are replacements for the filters. Please follow original manufacturers' instructions.

Before installation: Soak the filter in water for 10-15 minutes before installing.

After installation: run 2 to 3 gallons of water through the filter before using.

To Remove

- 1: Shut off water and release line pressure
- 2: Hold the filter and turn it counter-clockwise until the rotation stops.
- 3: Pull the filter down to remove it from the head

To Install

- 1: Aline the new filter and insert it into the head.
- 2: Turn the new filter clockwise until it stops.
- 3: Open the clock water valve and run the water through the filter system for several minutes. *Refer to filter label for specific time.*

*After installation, please check for any leakage. Installer is responsible to make sure there is no leakage. If there is any leakage, give us a call at 1-888-223-6762 ext. 102. Our office hours are Monday to Friday, 8:30 am to 4:30pm PST.