folio21

Assembly Instructions

Dresser & Chest & Media Chest


Model#: 683&680-002/009/017

Diagram 1

Thank you for purchasing this quality product.

Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment. Identify and count all parts and compare with the Parts List below.

***Caution: Please read all instructions carefully before starting the assembly process. These items can be cumbersome and heavy for some people. Therefore, the assistance of one or more people is recommended in order to prevent personal injury and insure the items are not damaged during the assembly process.



No.	Hardware List		Q'ty
A		NJT 5/16"	8
В		Lock Washer 5/16"	8
C	0	Flat Washer 5/16"	8
D	5	WRENCH 12mm	1

Note:

• Keep all hardware parts out of the reach of children.

Do not use substitute parts. Contact your dealer for replacement parts.
Keep these instructions for future reference.

Cleaning instruction: Wipe surface to be cleaned with damp cotton cloth; dry immediately with soft dry cotton cloth to remove all moisture.