


尺寸210X148mm *4张 成型(打钉)/ 148X105mm *16P



FEDERAL COMMUNICATIONS COMMISSION (FCC) STATEMENT

(READ AND FOLLOW ALL SAFETY INSTRUCTIONS)

Holiday show home™ APP

Quick Start Guide

Scan QR code to view product details and feature video.

www.ishowtree.com

(SAVE THESE INSTRUCTIONS)

Important Safety Instructions

Use and Care Instructions:

- When the product is placed on a live tree, the tree should be well maintained and fresh. Do not place on live trees in which the needles are brown or break off easily. Keep the tree fresh with water.
- If the product is placed on a tree, the tree should be well secured and stable.
- Before using or moving, inspect product carefully. Discard any products that have cut, damaged, or frayed wire insulation or cords, cracks in the lampshade or enclosure, loose electrical connections and wires.
- When using the product, carefully remove the product from wherever it is placed, including trees, branches or bushes, to avoid any undue strain or stress on the product conductors, connections, and wires.
- When not in use, store neatly in a cool, dry location protected from sunlight.

User Servicing Instructions:

Replace the fuse:

- Grasp plug and remove from the receptacle or other outlet device. Do not tug by pulling it.
- Open fuse cover. Side door fuse access cover on top of attachment plug always towards body.
- Remove fuse carefully.
- Risk of fire. Replace fuse only with 3 Amp, 125 Volt fuse (provided with product).
- Close fuse cover. Side door fuse access cover on top of attachment plug.
- Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged.

If connecting to a lighting string that does not have a Wattage (W) rating. Round on the tag with a pencil the size of the plug, calculate the wattage as follows: Multiply the current (A) which is on the tag type tag by 120.

For Example: Lighting string is rated 120V, 60Hz, 0.2 Amps, 0.2*120=24 Watt. Add the wattage of each light string together for a total of 216 Watts or less. (Do not exceed 216 Watts)

2 You need to turn on the Bluetooth first, and then open app

Your Bluetooth will connect the products automatically

Smart device must be compatible with Bluetooth 4.0 and above

Smartphone compatibility

- Android 4.3 or higher version, Supporting 4.0 Bluetooth.
- iOS 7.0 or higher version.
- iPhone: 4S, 5, 5S, 6, 6+, 6S, 6S+, SE, 7+, 8, 8+, X.
- iPad: iPad3, iPad mini (1, 2, 3, 4 series).
- iPad Air (1, 2 series), iPad Pro.
- iPad touch

Frequently Asked Questions

Q: My App can't connect with my products / devices

A: Connectivity issues mainly occur because of a weak bluetooth signal. Try these steps and see if they help the connection:

- Shorten the distance between your phone and the product.
- Turn off bluetooth functionality on your phone, and turn back on again, try reconnecting the App with device again.
- If the Above two options fail, then try cutting the power supply, take the plug out of the socket. Once clear for a few seconds place the plug back in to the socket and turn the power back on. Try reconnecting the App with device again.

Q: App can connect with devices, but there are no product numbers displaying on the App, or product numbers are visible, but App cannot connect and control the products.

A: 1. This could be because of a bad connection to the power supply. Unplug and insert the plug into the socket again, and turn on the power again.

2. If the present password is different between the products and App, then reset the products (To do this, cut the power supply and plug into a socket, repeat this for 3 times quickly).

3. If the above options fail, then exit the App close it down completely then turn the App back on again.

Q: If the product numbers visible are more than the actual products.

A: The App may likely be connecting with nearby products. Try setting a password for the products.

Q: If products change their mode without being controlled.

A: This could be because of a nearby neighbor using the App, you need to set a password for the products.

4 Setting chasing functions

Operate App in the following order

Functional description

- Contains 3 kinds of products: C6, C7 & Icicle
- Product display area
- Control the direction of the light flicker: left or right
- Overall effect display
- Hints and help
- Contains 1 kind of products: LED Light Strip
- Flashing light, limit its location
- Set the sequence of light flicker
- Chasing Mode: The chasing function mode supported for C6, C7, Icicle, Icicle, Polar Light and Color Show Modes.

More information about Showhome products

11 product parameters:

No.	Product Name	Picture	SKU No.	Describe
1	C6 Lights (E63767)		(In store) 1003182049 (On line) 1003144383	Function: 1. RGB Lights 2. Timer 3. Function: 29 kinds of theme colors Standard: 10 kinds of patterns 3 kinds of theme shows selected 4. with APP-Bluetooth Smart controlled control distance: >50m 5. with auto setting string lights Illuminate sequentially
2	C9 Lights (E63767)		(In store) 1003182057 (On line) 1003144389	Function: 1. RGB Lights 2. Timer 3. Function: 29 kinds of theme colors Standard: 10 kinds of patterns 3 kinds of theme shows selected 4. with APP-Bluetooth Smart controlled control distance: >50m 5. with auto setting string lights Illuminate sequentially
3	Icicles (E63767)		(In store) 1003182054 (On line) 1003144388	Function: 1. RGB Lights 2. Timer 3. Function: 29 kinds of theme colors Standard: 10 kinds of patterns 3 kinds of theme shows selected 4. with APP-Bluetooth Smart controlled control distance: >50m 5. with auto setting string lights Illuminate sequentially
4	Snow Flakes (E63767)		(In store) 1003182073 (On line) 1003144400	Function: 1. RGB Lights 2. Timer 3. Function: 29 kinds of theme colors Standard: 10 kinds of patterns 3 kinds of theme shows selected 4. with APP-Bluetooth Smart controlled control distance: >50m 5. with auto setting string lights Illuminate sequentially
5	Christmas Tree (E63767)		(In store) 1003182093 (On line) 1003144380	Function: 1. RGB Lights 2. Timer 3. Function: 29 kinds of theme colors Standard: 10 kinds of patterns 3 kinds of theme shows selected 4. with APP-Bluetooth Smart controlled control distance: >50m 5. with auto setting string lights Illuminate sequentially
6	LED Spotlights (E63767)		(In store) 1003182076 (On line) 1003144384	Function: 1. RGB Lights 2. Timer 3. Function: 29 kinds of theme colors Standard: 10 kinds of patterns 3 kinds of theme shows selected 4. with APP-Bluetooth Smart controlled control distance: >50m 5. with auto setting string lights Illuminate sequentially

5 Setting password

Operate App in the following order

Functional description

- Product display area
- Overall effect display
- Hints and help
- Current: View the current password with a picture
- No password: See no password device set
- Unknown: Devices that are different from the current password
- Reset the password: Press the electronic device and insert the plug into the power outlet for 3 times during 10 seconds, you can get the password. If the password is reset successfully, the light will be green.

1 Search "Showhome App" to download the APP from

Download on the App Store
GET IT ON Google Play

OR

Scan QR Code to download

(iOS) (Android)

Important Safety Instructions

CAUTION

- To reduce the risk of fire or electric shock, do not attempt to replace lamps or modify string.
- To reduce the risk of fire and electric shock: a) Do not install on trees having needles, leaves or branch coverings of metal or materials which look like metal, and b) Do not mount or support string in a manner that can cut or damage wire insulation.

Model No.: AL 91A, AL 91B, AL 91D, AL92A, AL92B, AL92C, AL93

There could be a delay of 10 seconds before your phone fully sync's with your App, depending on what phone you use.

3 Control your products with the below 11 main functions on your App

- Light Shows
- Showhome Products
- Product Mode
- Laser Projector Control
- Function Settings
- Timer Settings
- Color Reference
- Laser Projector Mode
- Color Mode Of Laser Projector Motor
- ON / OFF

Important Safety Instructions

When using electrical products, basic precautions should always be followed including the following:

- Read and following all safety instructions.
- Do not use electrical products outdoors unless marked suitable for indoor and outdoor use. When products are used in outdoor applications, connect the product to a Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.
- This seasonal product is not intended for permanent installation or use.
- Do not mount or place near gas or electric heaters, fireplace, candles or other similar sources of heat.
- Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
- Do not let lamps rest on the supply cord or on any wire.
- Unplug the product when leaving the house, when resting for the night, or if left unattended.
- This is an electric product not a toy! To avoid risk of fire, burns, personal injury and electric shock it should not be played with or placed where small children can reach it.
- Do not use this product for other than its intended use.
- Do not hang ornaments or other objects from cord, wire, or light string.
- Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
- Do not cover the product with cloth, paper or any material not part of the product when in use.
- The product employs overload protection (fuse). A blown fuse indicates and overrated current-circuit situation. If the fuse blows, unplug the product from the outlet. Also unplug any additional strings or products that may be attached to the product. Replace the fuse as per the user servicing instructions. Follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded.
- Read and follow all instructions that are on the product or provided with the product.
- Save these instructions.

Show Home App+

ShowHome App is the most advanced way to control all your lights. Easy switch between colors and lighting effects. Combine colors with lighting effects and find the setting that works best for you.

4.1 Demonstration

Operate App in the following order

More information about Showhome products

11 product parameters:

No.	Product Name	Picture	SKU No.	Describe
7	Condy Cones (E63767)		(In store) 1003182071 (On line) 1003144383	Function: 1. RGB Lights 2. Timer 3. Function: 29 kinds of theme colors Standard: 10 kinds of patterns 3 kinds of theme shows selected 4. with APP-Bluetooth Smart controlled control distance: >50m 5. Multiple color-Super brightness 6. Control over 100 sets synchronized Standard / Approved: FCC / UL / Bluetooth Certified
8	LED Light Strip		(In store) 1003182145 (On line) 1003144386	Function: 1. RGB Lights (R,G,B,17) 2. RGBW Lights (R,G,B,W,10) 3. Timer 4. Function: 29 kinds of theme colors Standard: 10 kinds of patterns 3 kinds of theme shows selected 5. with APP-Bluetooth Smart controlled control distance: >50m 6. with auto setting string lights Illuminate sequentially
9	Laser RGB 3D Hologram Projector		(In store) 1003182150 (On line) 1003144380	Function: 1. RGB Lights (R,G,B,17) 2. RGBW Lights (R,G,B,W,10) 3. Timer 4. Function: 29 kinds of theme colors Standard: 10 kinds of patterns 3 kinds of theme shows selected 5. with APP-Bluetooth Smart controlled control distance: >50m 6. with auto setting string lights Illuminate sequentially
10	light Ball		(In store) 1003182102 (On line) 1003144382	Function: 1. RGB Lights (R,G,B,17) 2. RGBW Lights (R,G,B,W,10) 3. Timer 4. Function: 29 kinds of theme colors Standard: 10 kinds of patterns 3 kinds of theme shows selected 5. with APP-Bluetooth Smart controlled control distance: >50m 6. with auto setting string lights Illuminate sequentially
11	RGB Show Tree		(Available on line only) 1003144381	Function: 1. RGB Lights (R,G,B,17) 2. RGBW Lights (R,G,B,W,10) 3. Timer 4. Function: 29 kinds of theme colors Standard: 10 kinds of patterns 3 kinds of theme shows selected 5. with APP-Bluetooth Smart controlled control distance: >50m 6. with auto setting string lights Illuminate sequentially

5.1 Demonstration

Operate App in the following order

6 Color Reference

There are 29 color patterns to choose from

Slide up and down to click selection

List of color patterns

1 White	11 Magenta	21 Christmas day
2 Red	12 Cyan	22 Valentines' day
3 Blue	13 Yellow	23 Independence day
4 Green	14 Purple	24 Thanksgiving Day
5 Orange	15 Cold white	25 St. Patrick's day
6 Pink	16 Warm white	26 Halloween
7 Aqua	17 Spring	27 Sun
8 Gold	18 Summer	28 Earth
9 Fuchsia	19 Autumn	29 Multi Color
10 Lawn green	20 Winter	