


RYOBI
18 Volt Grass Shear/Shrubber
Model Number 107269001
Item Number P2900
Repair Sheet

FIGURE A



RYOBI GRASS SHEAR/SHRUBBER – MODEL 107269001, ITEM NUMBER P2900

FIGURE A PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY	KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	672729001	O-Ring.....	1	19	230172001	Motor and Pinion Assembly.....	1
2	660204013	Screw (M3 x 8.5 mm, Flat Hd.)	8	20	770312009	Red Lead (75 mm).....	1
3	302347001	Motor Mount Assembly.....	1	21	302311001	Knob Assmely.....	1
4	340193001	Trigger Assembly	1	22	670914001	Washer (ID 6.5 x OD11 x 0.3t).....	2
5	940705299	Logo Label.....	1	23	302350003	Hedge Trimmer Blade Assembly.....	1
6	670028003	Washer (OD5.7 x ID3.1 x 0.8mm).....	2	24	760689001	Switch	1
7	672752001	Torsion Spring.....	1	25	672728001	Washer (OD15 x 8.4 x 0.3t).....	1
8	340197001	Housing Assembly	1	26	770311164	Black Lead (150 mm)	1
9	660206058	Screw (M3.5 x 12mm, Pan Hd.).....	2	27	670499001	Compression Spring	1
10	940851076	Warning Label (Left)	1	28	300001001	Contact Plate	1
11	660206059	Screw (M3.5 x 16 mm, Pan Hd.).....	7	29	770312177	Red Lead (150 mm).....	1
12	940851077	Warning Label (Right).....	1	30	516712001	Step Gear.....	1
13	940851078	Icon Warning Label.....	1	31	516711001	Gear	1
14	516819002	Scabbard	1		Not Shown		
15	941588098	Data Label.....	1		991000628	Operator's Manual	
16	660086009	Screw (M3 x 8 mm).....	2		8-4-15		
17	900205004	Sheath.....	1		(Rev:01)		
18	302348001	Grass Shear Blade Assembly	1				