

OUTDOOR WALL LANTERN INSTALLATION INSTRUCTIONS MODEL NOS. 7787-02B, 7787-02BZ, 7787-04B, 7787-07B

Congratulations on your purchase of a Newport Crest Outdoor Wall Lantern. You have purchased a safe, dependable, and easy-to-install lighting system. You can use this fixture at home for outdoor lighting applications. WHAT'S INCLUDED: A - Wall Lantern B - Fixture Mounting Screws (2) C - Swivel Mounting Bracket D - Mounting Bracket Screws (2) E - Wire Connector (3) F - Nut Caps (2) Tools Required: Phillips Screwdriver, Silicone Sealant or Caulk IMPORTANT SAFETY INFORMATION THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH ALL APPLICABLE INSTALLATION CODES. IF YOU ARE NOT FAMILIAR WITH ELECTRICAL WIRING. IT IS RECOMMENDED THAT YOU SECURE THE SERVICES OF A WELL QUALIFIED ELECTRICIAN WHO CAN ASSURE THAT THIS INSTALLATION MEETS LOCAL, STATE, AND NATIONAL CODES. BE SURE POWER IS TURNED OFF AT THE MAIN POWER PANEL OR FUSE BOX PRIOR TO INSTALLATION OR REPLACING FIXTURE. Before installing this fixture, be sure to check with local ordinances regarding approved outdoor lighting. This fixture style may not be allowed in some areas. This fixture is for outdoor use only. This fixture should be mounted to a grounded junction box marked for use in wet locations. The electrical system and the method of connecting the fixture to the system must be in accordance with local, state, and national electric codes. • • This fixture is to be connected to a 120 volt, 60 Hz power source. Connecting to a different power source may create a hazard and will void the warranty. This fixture is suitable for wet locations. Do not use near or around flammable/combustible material or liquids. When replacing the lamp (bulb), use only Type A medium base lamp (bulb) - 60 Watt Maximum. Never use a lamp (bulb) with a higher wattage than the stated maximum allowed on the fixture. Using a higher wattage lamp may cause a fire hazard and/or damage to the unit. The lamp (bulb) and fixture can get hot during use. Turn off the power and allow the fixture to cool down for at least 10 minutes prior to working on the unit. Do not attempt to open the fixture. There are no serviceable parts inside. Always use safety precautions. Safety glasses and gloves should be worn during installation. CLEAN FIXTURE ONLY WITH MILD SOAP AND WATER, AVOID SPRAYING WITH CLEANSERS, INSECTICIDES, AND PESTICIDES THAT ARE PETROLEUM BASED HYDROCARBON PRODUCTS. THESE WILL DEGRADE LUMINAIRE. PRIOR TO INSTALLATION: Carefully read through the entire installation instructions before installing this security light fixture. WARNING: BE SURE POWER IS OFF AT MAIN POWER PANEL/FUSE BOX BEFORE INSTALLING OR REPLACING FIXTURE. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODES BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED. INSTALLATION INSTRUCTIONS BE SURE POWER IS TURNED OFF AT THE MAIN POWER PANEL OR FUSE BOX PRIOR TO JUNCTION INSTALLATION OR REPLACING FIXTURE. **FIGURE 1** BOX 1. Remove old lighting fixture. If installing at a new location, contact a qualified electrician. 2. Insert two (2) Fixture Mounting Screws (B), as shown in Figure 1 and 3, through back (B) of Swivel Mounting Bracket (C). 3. Attach Swivel Mounting Bracket (C) onto the junction box using two (2) Mounting Bracket Screws (D). \odot Pull the supply wires from the junction box and past the Swivel Mounting Bracket (C) in preparation for wiring. 4. WIRING – See Figure 2 (C) a. Connect the Black wire from Wall Lantern (A) to the Black wire of the supply circuit **GROUND SCREW** using Wire Connectors (E). Connect the White wire from Wall Lantern (A) to the White wire of the b. (D) supply circuit using Wire Connectors (E). Connect the Ground wire from Wall Lantern (A) to Ground wire of the supply C. circuit using Wire Connectors (E). NOTE: If there is no Ground wire from the supply circuit, connect Black Black Ground wire from Wall Lantern (A) to green Ground screw (E) located on Swivel Mounting Bracket (C). 120 Volt d. Insert wires into junction box. Power White White (A) (A) 5. Attach Wall Lantern (A) to junction box by inserting two (2) Supply/ Junction (E) Fixture Mounting Screws (B) through mounting holes on Wall Lantern (A) Box and then secure using two (2) Nut Caps (F) as in Figure 3. \square П Ground Ground Tighten Nut Caps (F) clockwise. 6. Install Type A Medium Base lamp (bulb - not included)) into socket housing. Lamp wattage NOT to exceed 60 Watts. See 'Installing or (C) **FIGURE 2** Replacing Lamp' Section. 7. IMPORTANT: Apply a weatherproof silicone caulk or sealant around **FIGURE 3** the fixture base to reduce chance of water leaking into the fixture body. 8. Turn ON the power. INSTALLING OR REPLACING LAMPS 1. WARNING: Turn off the power and allow the fixture to cool down for at least 10 minutes prior to working on the unit. 2. Install Type A Medium Base lamp (bulb - not included)) into socket housing. Lamp wattage NOT to exceed 60 Watts. 3. To remove existing lamp (bulb) gently twist lamp (bulb) counter-clockwise until it becomes free of fixture. Install new lamp (bulb) by turning clockwise. Do not over-tighten lamp (bulb). Always use safety precautions. Handle lamp by base. CAUTION o Risk of electric shock. Do not open lamp (bulb). No user serviceable parts inside. GLASS IS BREAKABLE. WEAR PROTECTIVE GLOVES AND EYE WEAR WHEN HANDLING. n TROUBLESHOOTING Does not function at all • Make sure wall switch (if applicable) is ON and that the wiring is correct.

- Check that the circuit breaker, fuse, and main circuit breaker or main power switch are ON.
- Check lamp (bulb).

LIMITED LIFETIME WARRANTY - This product is warranted to be free from defects in material and workmanship for life of product. If a defect occurs, call 1-800-562-5625 for instructions on how to have defective product repaired or replaced free of charge. LIMITATIONS - This warranty only covers Newport Crest assembled lighting products and accessories and is not extended to other components, Lamp Bulb(s), or equipment used on the product. Warranty extends to original purchaser of product. Receipt or other approved proof of purchase required for warranty service. NOT LIABLE FOR INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. NOT COVERED - Product failure not relating to faulty material or workmanship, corrosion of brass components, reimbursement for installation or unauthorized service.