

# Quick Start Guide

## 1 Download and install the Nightingale Sound app on your smartphone.

Search for "Nightingale Sound" in the app stores.



## 2 Plug Nightingale into a wall outlet in your room.

It's important that the unit is plugged in before setting it up. For the best performance, choose an outlet close to your bed.

## 3 Launch the Nightingale Sound app to set up Nightingale.

You will need access to your email account on your smartphone to complete setup. Once your Nightingale is set-up, you can control it through the mobile app or any supported web browser at [www.controlnightingale.com](http://www.controlnightingale.com)

# Getting Started Tips



## Traveling often?

We recommend you set up Nightingale via Bluetooth for easy connectivity from hotel rooms.

---



## Adding more Nightingales?

You can add more Nightingales and bedrooms from the app.


---



## Smart home?

Check out [meetnightingale.com/smarthome](http://meetnightingale.com/smarthome) for ways to connect via Google Home, Amazon™ Alexa™, and IFTTT.

# Technical Specifications



## Physical Dimensions:

Height 4.3", Width 2.7", Depth 1.7" (Depth is 1" when it is plugged in)

**Weight:** 2.25 oz.

**Voltage (pass-through):** 110 V

**Amperage (pass-through):** 15 A

**Number of Speakers:** 2

**Sound Pressure Range:**

0 - 60 dB (SPL)

## Radios:

Wi-Fi: 2.4 GHz

Bluetooth LE: 2.4 GHz

**Communication Security:** AES

## Patents & Trademarks:

U.S. Patent Application Pending

Patent Cooperation Treaty (PCT) Patent Application Pending

U.S. and Foreign Design Patent Applications Pending

## Warranty:

1-year limited warranty. Visit [meetnightingale.com/warranty](https://meetnightingale.com/warranty) for details

For more information visit [meetnightingale.com](https://meetnightingale.com)  
For technical support visit [meetnightingale.com/support](https://meetnightingale.com/support)

