


## INSTRUCTIONS:

1. Remove old aerator from faucet. Use wrench if necessary.
2. Remove any old washers that might be caught inside the spout.
3. Clean the threads on faucet for easier installation.
4. Install adapter onto spout by hand.
5. Connect regular female aerator or any device with regular female threads (not provided).
6. Turn on faucet. If leak occurs, tighten more firmly.

## INSTRUCCIONES:

1. Quite el viejo aireador del grifo. Utilice una llave inglesa de ser necesario.
2. Quite todas las arandelas viejas que pudieran haber quedado atrapadas dentro del surtidor de agua.
3. Limpie las roscas del grifo para una instalación más fácil.
4. Instale el adaptador en forma manual.
5. Conecte aireador regular hembra o cualquier dispositivo con roscas hembra regular (no proveído).
6. Abrir el grifo. Si ocurre un escape, ajuste más firmemente.

For small female faucets with inside threads:



**Warning:** Product may contain sharp edges, use caution when installing.

**Advertencia:** Este producto puede que tenga los bordes filosos, use precaución al instalar.