

HOME


DECORATORS
COLLECTION

Item #1004019254

Model #BF-27007-IV-TW

USE AND CARE GUIDE

THD PRODUCT NAME: VANITY STOOL FARMHOUSE



Questions, problems, missing parts? Before returning
to the store, Call Customer Service
8 a.m. - 7p.m., EST, Monday - Friday, 9 a.m. - 6 p.m.,
EST, Saturday

1-800-998-7021
HOMEDEPOT.COM/HOMEDECORATORS

THANK YOU

*We appreciate the trust and confidence you have placed in Home Decorators Collection through the purchase of this stool .
We strive to continually create quality products designed to enhance your home. Visit us see our full line of products available
for your home improvement needs.*

Thank you for choosing Home Decorators Collection!

Table of Contents

Table of Contents.....	2	Assembly.....	5
Safety Information.....	2	Maintenance.....	6
Warranty.....	2	Care and Cleaning.....	6
What Is Covered.....	2		
What is Not Covered.....	2		
Pre-Assembly.....	3		
Planning Assembly.....	3		
Tools Required.....	3		
Hardware Included.....	3		
Package contents.....	4		

Safety Information

Read and understand these instructions before attempting to install or use this product.



CAUTION: Use caution when lifting heavy objects. Lifting heavy objects improperly could cause serious injury.



NOTE: Handle with care. Do not drop or handle roughly, as this could damage the linen cabinet.

Warranty

3 YEAR WARRANTY

WHAT IS COVERED

We guarantee this product to be free of manufacturing defects to the original purchaser for three years.

WHAT IS NOT COVERED

This warranty does not cover commercial use, acts of nature, and abusive use.

Pre-Assembly

PLANNING ASSEMBLY

Check the product for damage before installation. If any part of the product is missing or damaged, contact the Customer Service Team at 1-800-998-7021.

TOOLS REQUIRED



Phillips
screwdriver

HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.



_____ A



_____ B



_____ C




_____ D

Part	DESCRIPTION	Quantity
A	BOLTS	8
B	SPRING WASHER	8
C	FLAT WASHER	8
D	ALLEN WRENCH	1

Pre-Assembly


PACKAGE CONTENTS



Part	DESCRIPTION	Quantity
1	SEAT CUSHION	1
2	FOOT	4

1 ASSEMBLY BENCH

- Align the holes of 4 feet (2) with the holes of the seat cushion(1) and lock them with 8 bolts (A), 8 flat washer (C) and 8 spring washer (B), as shown in the figure.



Maintenance

- ❑ If your furniture is stained or otherwise damaged during use, contact a professional for repairs.

Care and Cleaning

- ❑ Use a soft, clean cloth that will not scratch the surface when dusting.
- ❑ Use of furniture polishes is not necessary. Should you choose to use polishes, test the polish in an inconspicuous area before using over the entire surface of the product.
- ❑ Using solvents of any kind on your furniture may damage the finish.
- ❑ Never use water to clean your furniture as it may cause damage to the finish.
- ❑ Always use coasters under beverage glasses and flowerpots.
- ❑ Liquid spills should be removed immediately. Using a soft, clean cloth, blot the spill gently. Avoid rubbing.
- ❑ Always use protective pads under hot dishes and plates. Heat can cause chemical changes that may create spotting within the furniture finish.
- ❑ Use care as stains or marks from crayons or ink markers will be difficult to remove.
- ❑ Be sure to immediately clean red wine or soda stains within 30 minutes or the surface will stain.

HOME DECORATORS COLLECTION

**Questions, problems, missing part? Before returning to the store,
call Home Decorators Collection Customer Service
8 a.m. - 7p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday**

1-800-998-7021

HOMEDEPOT.COM/HOMEDECORATORS

Retain this manual for future reference.