

ProLED® 4" Downlight Replaceable Trim Installation Instructions



NOTE: USE THE FOLLOWING HALCO TRIMS WITH ANY OF THE HALCO DOWNLIGHT FIXTURES LISTED BELOW.

4" Downlight Fixture

Product #	Product Code
99924	DL4FR9/927/RT/LED
99925	DL4FR9/930/RT/LED
99926	DL4FR9/940/RT/LED
99927	DL4FR9/950/RT/LED

4" Trim Options

Product #	Product Code
99934	DL4/WB
99935	DL4/WSS
99936	DL4/BN
99937	DL4/ORB

INSTALLATION INSTRUCTIONS:

STEP 1:

Remove trim from Downlight by twisting counter-clockwise (looking at the lens) which will unlock the latch.

STEP 2:

Replace with new trim by aligning latch with the slots on the flange and twisting clockwise to lock the latch and trim in place.

STEP 3:

Check installation to make sure the trim is securely locked in place.

STEP 4:

Replace Downlight Fixture into recessed can.

