

CAUTIONS

When searching for treasure with your Garrett detector, observe these precautions:

- Never trespass or hunt on private property without permission.
- National and state parks / monuments and military zones, etc. are absolutely off-limits.
- Avoid areas where pipelines or electric lines may be buried. If found, do not disturb and notify proper authorities.
- Use reasonable caution in digging any target, particularly if you are uncertain of the conditions.
- If you are unsure about using your metal detector in any area, always seek permission from the proper authorities.

CARING FOR YOUR ACE 300 DETECTOR

Your Garrett detector is rugged, designed for outdoor use. However, as with all electronic equipment, there are some simple ways you can care for your detector to maintain its high performance.

- Avoid extreme temperatures as much as possible, such as storing the detector in an automobile trunk during the summer or outdoors in sub-freezing weather.
- Keep your detector clean. Disassemble the stem and wipe it, the control housing, and the searchcoil with a damp cloth when necessary.
- Remember that your searchcoil is submersible, but your control housing and connectors are not.
- Protect your control housing from heavy mist, rain and blowing surf.
- When storing for longer than one month, remove the batteries from the detector.
- When changing batteries, use quality alkaline or rechargeable batteries, and replace with all new batteries for optimum performance.

ACE 300 WARRANTY & SERVICE

Your *ACE 300* detector is warranted for 24 months, limited parts and labor, but does not cover damage caused by alteration, modification, neglect, accident or misuse.

In the event you encounter problems with your *ACE 300* detector please read through this Owner's Manual carefully to ensure the detector is not inoperable due to manual adjustments. Press and hold the power button for 5 seconds to return to the recommended factory settings.

You should also make certain you have:

1. Checked your batteries and connectors. Weak batteries are the most common cause of detector "failure."
2. Contacted your dealer for help, particularly if you are not familiar with the *ACE 300* detector.

In the event that repairs or warranty service are necessary for your *ACE 300*, contact the local retail outlet where your detector was purchased. To avoid excessive shipping and import charges, do not attempt to return a Garrett product to the factory in the United States.

Information on international warranty/repair needs can be found on the Garrett website: www.garrett.com. Click on the Sport/Hobby Division and then the Technical Support page for more details.