

Simply-A-Blast (Part #6133300)

Description	PART #	
*MOTOR	513000	
PUSHER	513110	
CHOPPER CASTING	513135	
BLADES	513003	
FRONT GLASS PANEL	513770	
SIDE GLASS PANEL	513775	
DOOR (13 1/16" x 13 1/16") (Optional accessory)	514195	
HINGE SET (Optional accessory)	512166	
MAGNET (Optional accessory)	512100	
TRAY	513436	
RUBBER FEET	540322	
SWITCH MOTOR	513025	
*SWITCH RESET	513005	
*POWER CORD	512092	
CUPHOLDER W/BRACKET (OPTIONAL)	513012	

*For use in Domestic (120v) models only

Export Parts (Part #6233310)

MOTOR	513000E	
SWITCH RESET	513006	
POWER CORD	512012	