



ES22 CORNER BOOKCASE OPERATING INSTRUCTIONS



WARNING

1. Do not use this product unless all screws and bolts are securely tightened.
2. Check that all screws and bolts are tight every three months or as needed.
3. Dispose of packing material properly. Do not use plastic cover as head covering. It may cause suffocation.
4. Do not use this product as a stepladder.
5. Use this product for its intended purpose only.
6. Use lower shelf for heavier items to help prevent tip-over.
7. In earthquake areas and when children are present use angle-braces or anchors to secure furniture to the wall to prevent tipping.
- 8. Intended for residential use only**

LIMITED WARRANTY

OSP Designs warrants, to the original purchaser its products to be free from defects in material and workmanship for a period of 90 days. Defects and damage from misuse, abuse, negligence, alteration, accident, vandalism, rusting, acts of nature or any other event beyond the control of OSP Designs is not covered. The warranty does not cover cosmetic damage that may result from normal use. Liability for incidental or consequential damages is excluded. The user assumes all risk of injury resulting from use of this product. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

To make a warranty claim, contact Customer Service, provide model number, sales receipt and description of the problem. It is the customer's responsibility to prepay freight on any components returned to the factory. OSP Designs will pay return freight on components covered under terms of warranty.

Our quality standards are among the highest in the industry. Sometimes, no matter how hard we try, there are times when hardware is missing. Our Parts Department will do everything possible to promptly remedy the problem. Contact us via email parts@officestar.net, by Fax 1-909-930-5629, or toll free parts number 1-800-950-7262, Monday through Friday 8:00 a.m. - 5:00 p.m. Pacific Time. OSP Designs P.O. Box 3520 Ontario, California 91761 USA

ES22 CORNER BOOKCASE ASSEMBLY INSTRUCTIONS


IMPORTANT NOTE:

1. Use hand tools only for assembly as power tools may cause damage
2. Carefully remove any staples used for packaging.


PART	QTY
1. Top Frame	1
2. Bottom Frame	1
3. Shelf 4 1/8" X 4 1/8"	1
4. Shelf 6" X 6"	1
5. Shelf 8 1/2" X 8 1/2"	1
6. Shelf 10 1/2" X 10 1/2"	1
7. Shelf 12 1/2" X 12 1/2"	1
8. Wood Screw	15
9. Small Wood Screw	3
10. Allen Wrench	1

Phillips Head Screwdriver also needed for assembly (not provided)

STEP 1



STEP 2



Remove all parts from carton, separate by part numbers indicated on parts list, and verify part quantities.

STEP 1 Stand Bottom Frame (2) in the open and upright position, Place Top Frame (1) on Bottom Frame (2) aligning plastic dowels of Bottom Frame (2), **SEE DETAIL A.**

STEP 2 Turn the three pre-attached metal plates of Bottom Frame (2) upward. Secure metal plates to Top Frame (1) using one Small Wood Screw (9) for each metal plate. **SEE DETAIL B. TIGHTEN ALL SCREWS COMPLETELY USING PHILLIPS SCREWDRIVER (not provided).** Attach Shelves (3-7) to assembled frames using three Wood Screws (8) for each shelf.

SEE DETAIL C. TIGHTEN ALL SCREWS USING ALLEN WRENCH (10).

ATTENTION: MAKE SURE ALL SCREWS ARE FULLY TIGHTENED BEFORE USING.