



# Wellington Arbor

---

Model# 11179      Assembly Instructions

## General Information

PLEASE READ THROUGH BEFORE BEGINNING ASSEMBLY.

IMPORTANT: Check boxes for Contents Listed

Check inside of parts as some parts are packaged inside of others

In the event of missing, damaged or defective parts please call our customer service dept. at 1-877-258-6020

When assembling components, place on a clean, flat non-abrasive surface to avoid scratches

## Tools Required

- ... Battery or Electric Drill with #2 phillips bit
- ... Tape Measure
- ... Hammer or Rubber Mallet (recommended)

<u>Part #</u>	<u>Description</u>	<u>Qty</u>
1	2" sq. x 84" Left Post	2
2	2" sq. x 84" Right Post	2
3	7/8 x 1 1/2 x 27 1/2" Outer Cross Rail	4
4	7/8 x 1 1/2 x 27 1/2" Inner Cross Rail	8
5	7/8 x 1 1/2 x 27 1/2" Middle Cross Rail	4
6	1 x 1 x 26 1/2" Vertical Rail	8
7	1 x 1 x 16 3/4" Vertical Rail	8
8	1 x 1 x 13" Vertical Rail	4
9	1 1/2 x 4 x 72" Arbor Top Rail	2
10	7/8 x 1 1/2 x 41" Arbor Top Cross Rail	8
11	7/8 x 1 1/2 x 18" Corner Brace	4
12	5 3/8" Arbor Top End Cap	4
13	Hardware Bag (includes:)	1
	2" sq." Post Cap	4
	7/8 x 1 1/2" End Cap	16
	1 1/4" Painted Screw	28
	3/4" Painted Screw	16
	Super Glue Tube	1
14	Arbor Ground Anchor Kit (includes:)	1
	16" Steel Ground Anchor (L-Shaped)	4
	#8 - 1" Painted Self Tapping Screw	8