

USE AND CARE GUIDE

Crestridge 3-Piece Padded Sling Balcony Height Set - Taupe Putty



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service.

8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

Table of Contents

Table of Contents	2
Safety Information	
Product Caution	2
Safety Warnings	
Warranty	2
What is Covered	2
What is Not Covered	2
Pre-Assembly	3
Planning Assembly	3
Hardware Included	
Table Package Contents	4

Table Assembly	5
Care and Cleaning	7

Safety Information

PRODUCT CAUTION

This set was made for the explicit purpose of providing outdoor functions and is not to be used as a toy. This product is intended for normal outdoor use; however, the manufacturer recommends storing and / or covering this set when any formidable / severe weather is approaching. Do not locate this product near open flames. Do not use this product as a support. Do not shake, lean or climb on the product. Children under the age of 10, near the product, should be supervised by a competent adult at all times.

SAFETY WARNINGS



WARNING: Please keep children out of the assembly area before assembly.



CAUTION: When not in use, secure the product in a cool and covered location.



WARNING: Do not place heavy objects on the table top.

Warranty

2 YEAR FRAME AND 2 YEAR FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for two years, and a two year limited warranty for the fabric.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.hamptonbay.com.

Pre-Assembly

PLANNING ASSEMBLY

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



NOTE: More than one person may be required to assemble this product.

HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	M6x16 BOLT	12+1
ВВ	d6.5xD13x1.0 WASHER	12+1
CC	4 mm Allen Key Wrench	1

Pre-Assembly (continued)

TABLE PACKAGE CONTENTS



Part	Description	Quantity
Α	Table top	1
В	Table leg	4
С	Center connector	1
D	Tile	4

Table Assembly

Connecting the table legs to the table top

- □ Place the table top (A) upside down on a soft surface.
- □ Attach the table legs (B) to the table top (A) using M6x16 bolts (AA) and d6.5xD13x1.0 washers (BB).



NOTE: Loosely tighten all the bolts using the hex wrench (CC).




Table Assembly (continued)

2 Attaching the leg connector

□ Attach the center connector (C) to the table legs (B) using M6x16 bolts (AA) and d6.5xD13x1.0 washers (BB).



NOTE: Loosely tighten all the bolts using the hex wrench (CC).





Table Assembly (continued)

3 Tightening the bolts and placing the tiles

- Once all of the bolts are in place, fully tighten the bolts.
- □ Turn the table right side up.
- □ Then put the tiles (D) onto the table top (A) carefully.
- Ensure all connections are secure before use.



Care and Cleaning

- □ For best results, clean the set with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- □ Do not clean with abrasive materials, bleach, or solvents.
- □ Store the set in a dry, sheltered place when not in use.
- Keep the set away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service.

8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday


1-855-HD-HAMPTON HAMPTONBAY.COM

Retain this manual for future use.



USE AND CARE GUIDE

Crestridge 3-Piece Padded Sling Balcony Height Set - Taupe Putty



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service.

8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

Table of Contents

Table of Contents	2
Safety Information	2
Product Caution	
Safety Warnings	
Warranty	2
What is Covered	2
What is Not Covered	2
Pre-Assembly	3
Planning Assembly	
Hardware Included	
Chair Package Contents	

Chair Assembly......5

Care and Cleaning......10

Safety Information

PRODUCT CAUTION

This set was made for the explicit purpose of providing outdoor functions and is not to be used as a toy. This product is intended for normal outdoor use; however, the manufacturer recommends storing and / or covering this set when any formidable / severe weather is approaching. Do not locate this product near open flames. Do not use this product as a support. Do not shake, lean or climb on the product. Children under the age of 10, near the product, should be supervised by a competent adult at all times.

SAFETY WARNINGS



WARNING: Weight limit for the chairs is 250 lb (113.39 kg) for each seat.



CAUTION: When not in use, secure the product in a cool and covered location.



WARNING: Please keep children out of the assembly area before assembly.



WARNING: Do not place heavy objects on the chair.

Warranty

2 YEAR FRAME AND 2 YEAR FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for two years, and a two year limited warranty for the fabric.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.hamptonbay.com.

Pre-Assembly

PLANNING ASSEMBLY

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



NOTE: More than one person may be required to assemble this product.

HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	M6x14 BOLT	10+1
BB	M6x35 BOLT	4+1
CC	d6.5xD13x1.0 WASHER	14+1
DD	4 mm ALLEN KEY WRENCH	1

Pre-Assembly (continued)

CHAIR PACKAGE CONTENTS



Part	Description	Quantity
Α	Seat Assembly	1
В	Left Leg	1
С	Right Leg	1
D	Cross Brace	1
E	Support Brace	1


Chair Assembly

Connecting the chair seat assembly to the chair leg

- □ Place the left leg (B) onto a non-abrasive surface, such as a carpet.
- □ At the front of the chair, fasten the seat assembly (A) to the left leg (B) by using M6x14 bolts (AA) and d6.5xD13x1.0 washers (CC).



NOTE: Loosely tighten all the bolts using the hex wrench (DD). Keep 3mm Gap. Don't fully tighten the Bolts.




2 Connecting the chair cross brace and support brace to the chair left leg

- Insert the support brace (E) into the left leg (B). The holes in the support brace (E) must be facing towards the inside of the chair. Fasten the support brace (E) to the left leg (B) by using M6x14 bolts (AA) and d6.5xD13x1.0 washers (CC).
- □ At the rear of the chair, fasten the cross brace (D) to the left leg (B) by using M6x14 bolts (AA) and d6.5xD13x1.0 washers (CC).



NOTE: Loosely tighten all the bolts using the hex wrench (DD).




3 Connecting the chair right leg to the chair seat assembly, cross brace and support brace

□ Repeat steps 2 and 3 for the right leg (C).



NOTE: Loosely tighten all the bolts using the hex wrench (DD).




4 Connecting the chair seat assembly to the chair legs

At the back of the chair, fasten the seat assembly (A) to the legs (B and C) by using M6x35 bolts (BB) and d6.5xD13x1.0 washers (CC).




NOTE: Loosely tighten all the bolts using the hex wrench (DD).



5 Tightening the bolts

- Turn the chair to its upright position.
- Once all of the bolts are in place, fully tighten the bolts.
- Ensure all connections are secure before use.



Care and Cleaning

- For best results, clean the set with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- □ Do not clean with abrasive materials, bleach, or solvents.
- □ Store the set in a dry, sheltered place when not in use.
- Keep the set away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service.

8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON HAMPTONBAY.COM

Retain this manual for future use.