



Part #	Description	QTY
1	Meat Pan	1
2	Meat Stomper	1
3	Stuffing Tube	1
4	Meat Stomper Cover	1
5	Left & Right Side Motor Housing	1
6	Screw st4x20	3
7	Screw st4x25	2
8	Grinder Head	1
9	Auger Drive Gear Screw m5x10	1
10	Auger Drive Gear SS Washer	1
11	Auger Drive Gear	1
12	Auger Drive Gear Plastic Washer	1
13	Auger Drive Gear Silicon Washer	1
14	Auger	1

Part #	Description	QTY
15	Knife	1
16	8mm Grinding Plate	1
17	4.5mm Grinding Plate	1
18	Plastic Stuffing Plate	1
19	Retaining Ring	1
20	Power Cord	1
21	Motor	1
22	Shock Proof Pad "A"	2
23	Inner Gear Case	1
24	Washer	4
25	Screw m5x12	4
26	Shock Proof Pad "B"	4
27	Washer	10
28	Shaft	1

Part #	Description	QTY
29	Straight Step Gear	1
30	Helical Step Gear	1
31	Large Output Gear	1
32	Outer Gear Case	1
33	Release Button Spring	1
34	Release Button	1
35	Release Button Rod	1
36	Screw st3x12	5
37	Head Attachment Flange	1
38	Screw st3x16	6
39	Rubber Seal	1
40	Front Face	1
41	Screw 2.5x8	4
42	Plug	1

Part #	Description	QTY
43	Circuit Board	1
44	Washer	4
45	Shaft	1
46	Foot	4
47	Shaft	1
48	Wire Clip	1
49	Spring	1
50	Spring	1
51	LED Cover	1
52	On/Off Switch	1
53	Reverse Button	1
54	Switch Panel	1
55	Power Cord Clip	1
56	Tie Wraps	2