

Quick Start Guide

Cleaning can be overwhelming, so we kept things simple. In just a few easy steps, Bob will be ready to work!

Here's What You'll Need:


All parts are included in Bob's box.




Flat Head
Screwdriver




Side Brush Screw
(short screw)




Side Brush



Charging Station




Charging Adapter



Before starting, remove the clear plastic covering on Bob's power switch and flip Bob's power switch on.


Step 1: Install the Side Brush

Secure the side brush into the socket on Bob's underside.




Step 2: Charge Bob

Place Bob on his charging station and allow him to charge. Line up the metal plates on Bob's underside with the nodes on his station.



Step 3: Let Bob Sweep!

Press the GO! button on Bob's cover.



Important Note:

Bob automatically returns to his charging station when low on battery. If Bob's having trouble finding his station, you will need to sync it. Refer to the Charging section of Bob's manual.

When Charging:

The battery bars flash and the word "charging" is lit.



When Fully Charged:

The battery bars remain still and the word "charging" is no longer lit.



Loving the Product?

Leave us a review! Rate us 5 stars and share your feedback on the site where you purchased Bob.

Not Impressed?

Let us help! Contact our support team at support@bobsweep.com or 1-888-549-8847. Our business hours are Monday – Friday, 9 a.m. – 5 p.m. Pacific Time.