



How to Keep Your Duck Cover Looking Like New

Proper care and use of your new Duck Cover will significantly increase the life of your Duck Cover and Duck Dome. Failure to adhere to care instructions may void the warranty.

- Keep your Duck Cover material clean:
 - Spot wash, hand wash or launder in a front-loading washing machine, using cold water and mild detergent only.
 - Hang to dry. **DO NOT PUT IN DRYER OR IRON.** Exposure to high heat can damage the fabric beyond repair.
 - Do not use abrasive cleaners or cleaners with bleach.
 - Avoid using abrasive cleaning tools. Use only a clean cloth, sponge or soft bristled brush.
- Keep your Duck Dome clean:
 - Wipe clean with water.
- Avoid pulling your cover across rough surfaces by folding or rolling it up before moving from one location to another.
- Avoid placing the Duck Dome near sharp objects during installation, removal and storage.
- Fold your Duck Cover and Duck Dome when not in use. Loosely fold or roll your Duck Dome to avoid creation of deep creases and possible damage.
- Always store your Duck Cover and Duck Dome dry.

Do not expose Duck Covers inflator to water and always store in a warm, dry place.