


Neato Vacuum Quick Start Guide

1 Plug in the charging base

Place the base 3 feet from any corner and make sure there is space in front of the charging base for the Neato Vacuum to dock.

NOTE: Ensure that the base is sitting up against a wall and is not tilted forward.




2 Select language and charge your Neato Vacuum

Place your Neato Vacuum up against the charging base.

The LCD screen will light up and prompt you to select a language for the display screen. Use the up and down arrows to select the language, then press **SELECT**.

Once the language is selected, the light around the **START** button will light up to let you know it is charging. When it is solid green in approximately 2 to 3 hours, it's ready to clean.




3 Start cleaning!


Press **START** to wake up the Neato Vacuum (you may have done this while taking it out of the box).

Press **START** again to begin vacuuming your floors!


NOTE: For best performance, remove small items from your floors, and secure any loose cables.



4 Empty the dirt bin



For best performance, empty the dirt bin after each cleaning cycle.



The light around the START button shows the vacuum's status:

Status light color	Meaning
Solid green	Fully charged and ready to clean
Pulsing green	Charging, but ready to clean
Pulsing amber	Charging, can't clean yet
Solid amber	Error, see vacuum's LCD screen

neato robotics®

Neato Robotics, Inc.
1916 Old Middlefield Way Suite A
Mountain View, CA 94043
www.NeatoRobotics.com

p/n 515-0001 rev 4C-US

Copyright © 2011 Neato Robotics, Inc. Neato Robotics is a registered trademark, and Neato XV-11 is a trademark of Neato Robotics, Inc.