




# Equipment Sizing Guide



Use the map above to determine your region and compare to the chart below to find your application size.

## 96% AFUE Gas Furnace 2-Stage, Variable Speed (Multi-Positional) Selection

SQ. FOOTAGE	Region 1	Region 2	Region 3	Region 4	Region 5	Furnace Size
	1130-1415	1220-1525	1365-1705	1660-2070	1855-2320	<b>60,000 BTU</b>
	1415-1875	1525-2025	1705-2265	2070-2750	2320-3080	<b>80,000 BTU</b>
	1875-2340	2025-2525	2265-2825	2750-3430	3080-3840	<b>100,000 BTU</b>
	2340-2805	2525-3025	2825-3380	3430-4105	3840-4600	<b>120,000 BTU</b>

**Residential Sizing:** The table and charts are intended to be used as a guideline for Residential applications only. The information is based on conventional window space (<15%), insulation and building construction (8 ft. ceiling height). When including a finished basement, use 1/2 of the finished basement square footage with the rest of the area being calculated.

**Mobile/Manufactured Home Sizing:** Refer to the Date Plate located in the electrical box or kitchen cabinets. For further assistance, call Hamilton's customer service department (800) 879-0123.