



LAWN SWEEPER EXPLODED VIEW



ITEM	PART NO	DESCRIPTION	QTY.	ITEM	PART NO	DESCRIPTION	QTY.
1	6004212-Y	SWEEPER HOUSING	1	18	6004023	PLUNGER KNOB	1
2	6003957	HEIGHT ADJUSTMENT HANDLE	1	19	6004022	PLUNGER SPRING	1
3	310061	NYLON INSERT LOCKNUT, 3/8-16 UNC	6	20	6004020	PLUNGER PIN	1
4	6003965	HITCH WELDMENT	1	21	6000539	DUST COVER	2
5	6004208	HITCH CROSS TUBE ASSEMBLY	1	22	6000733	1/4" -20 X 1" CARRIAGE BOLT	8
6	307034	HITCH MOUNT TUBE	2	23	3000716	WASHER, 1/4" SAE	4
7	3000543	3/8"-16 X 2" HEX BOLT	4	24	300065	1/4" -20 LOCK NUT	22
8	3000722	CURVED WASHER, 3/8" USS	4	25	307023	HOUSING, BEARING	2
9	310073	WASHER, 3/8" USS	4	26	6000731	RIGHT PINION ASSEMBLY	1
10	4075502	LOCKING BRACKET	2	27	6000730	LEFT PINION ASSEMBLY	1
11	6000222	SNAP BUTTON	2	28	6002313	SPIRAL BRUSH TUBE	1
12	307011	WHEEL (BUSHINGS INCLUDED)	2	29	307122	STEEL BRACKET	4
13	6000540	WHEEL BUSHING	4	30	307121	STEEL CLAMP	8
14	3000721	WASHER, 3/4" SAE	2	31	3000539	1/4" -20 X 1-1/4" BOLT	14
15	300081	COTTER PIN, 1/8" X 1-1/2"	2	32	6002314	BRUSH	2
16	307241	WHEEL CAP	2	33	307082	HITCH PIN	1
17	6004206	WHEEL WELDMENT	1	53	6004248	VINYL GRIP FOR HANDLE	1

HOPPER BAG EXPLODED VIEW



CubCadet

ITEM	PART NO	DESCRIPTION	QTY	ITEM	PART NO	DESCRIPTION	QTY
34	6004204	CENTER HOPPER FRAME	2	43	307032	CONNECTING TUBE	2
35	6000285	BOTTOM HOPPER FRAME	2	44	3000720	3/8" USS FLAT WASHER	2
36	6000284	TOP HOPPER FRAME	3	45	6004001	TENSION TUBE ASSEMBLY	1
37	6002316	HOPPER STOP BAR	1	46	307133	BAG ASSEMBLY HARDWARE	1
38	3000818	CLEVIS PIN, 3/8" x 1/2"	2	47	3000823	QUICK-RELEASE PIN	2
39	307083	HAIRPIN COTTER	6	48	307361	NYLON DUMP ROPE	1
40	6004247	HOPPER BAG	1	49	6000208	SNAP BUTTON	4
41	3000820	CLEVIS PIN, 1/4" x 1-1/4"	2	50	6004282	OWNERS MANUAL	1
42	6002318	HOPPER PIVOT ROD	1	51	6003894	BAG PULL HANDLE	1

REPAIR KITS

KIT	KIT NUMBER	PART NUMBER	PART DESCRIPTION	QTY
CC-4624V2 FRAME KIT	6004287	6004204	CENTER HOPPER FRAME	2
		6000285	BOTTOM HOPPER FRAME	2
		6000284	TOP HOPPER FRAME	2
PINION BEARING KIT	6000828	307022	BEARING ASSEMBLY	2
		6000731	RIGHT PINON ASSEMBLY	1
		6000730	LEFT PINION ASSEMBLY	1
BAG ASSEMBLY HARDWARE	307133	3000820	CLEVIS PIN, 1/4" X 1-1/4"	2
		307083	HAIRPIN COTTER	6
		3000818	CLEVIS PIN, 1/4" X 1/2"	2
		3000720	3/8" USS FLAT WASHER	2
		3000823	QUICK RELEASE PIN	2
		307082	HITCH PIN	1
		CONNECTING TUBE KIT	6004135	307034
1" SNAP BUTTON KIT	6004136	6000222	1" SNAP BUTTON	4
3/4" SNAP BUTTON KIT	6004137	6000208	3/4" SNAP BUTTON	4
DUST COVER KIT	6004138	6000539	DUST COVER	2
46" BRUSH KIT	6004288	6002314	46" SWEEPER BRUSH	2
WHEEL BUSHING KIT	6004141	6000540	WHEEL BUSHING	4
TENSION TUBE KIT	6004001	6004001	TENSION TUBE ASSEMBLY	
CC-4624V2 HOOD KIT	6004289	6004212-Y	SWEEPER HOUSING	1
		6004205	WHEEL ASSEMBLY	1
		4075502	LOCKING BRACKET	2
		6002314	46" SWEEPER BRUSH	2

Customer Service 1-800-652-2321

1. A description of the issue you are having
2. Photos of the issue that include an overall view and detailed view from multiple angles
3. If applicable, a short video showing the issue

If you believe this is a warranty related issue please see the warranty page in this manual

Replacement Parts:

If you are ordering replacement part(s) for your product, please note that some parts are only available as a repair kit. You can reach our Customer Service Department at 1-800-652-2321

1. First locate the part on the Exploded View page (page 11 & 12)
2. Take note of the part number
3. If the part number is on the Repair Kits page, use the kit number to order your replacement parts
4. If the part number is not on the Repair Kits page, use the part number to order your replacement part