

W Unlimited Collection Outdoor Faux Sea Grass Garden Patio Collection Care and Maintenance

Frames, Aluminum Table Tops and Finishes

- Be careful to never allow water to build up in frames as this could cause corrosion and freeze damage in cold climates.
- Wash all frames and/or aluminum table tops with a solution of mild soap and water.
- Rinse with clean water and dry with a soft absorbent cloth towel.
- Frames can be treated with a liquid wax for maximum protection against UV rays and/or salty damp air.

All-Weather Resin Wicker

- All-weather wicker is made of either PVC, Polyvinyl Chloride or PE, Polyethylene.
- Clean by washing frequently with mild soap and warm water.
- Do not use abrasive materials or cleansers.
- Commercial vinyl protectors may stain the cushions.

Fabrics and Cushions

- If your set includes cushions, slings, and/or an umbrella they may be cleaned by hand with a solution of soap and water with a thorough, clean water rinse.
- Mildew and heavy stains can be removed with a quality commercial outdoor furniture cleaner and protectant.
- Note: Never dry clean or machine wash cushions, slings or umbrella covers as this will result in shrinkage or damage.
- Do not steam or use water at temperatures above 100°F when washing
- After cleaning cushions, stand on an end and allow to drip dry.
- Never use a commercial or home dryer to tumble dry fabric goods.
- Maintain your cushions and slings by storing them in a dry area out of the elements or cover them with commercially available furniture covers when not in use.
- If your furniture is being used in an area where birds and trees are plentiful, covering the cushions is especially recommended.
- **Do not use bleach or solvents to clean any product! This will void the warranty.**