


## 10 EXPLODED VIEW



| Item No. | Part No.    | Description           | Qty |
|----------|-------------|-----------------------|-----|
| 1        | C1101578-00 | Cord retainer         | 2   |
| 2        | 322011635   | Screw                 | 6   |
| 3        | 341101936   | Gun holder            | 1   |
| 4        | 322011628   | Screw                 | 10  |
| 5        | 311201936   | Upper handle assembly | 1   |

|    |             |                        |   |
|----|-------------|------------------------|---|
| 6  | 333011936   | Hose hook              | 1 |
| 7  | C1101575-00 | Front panel assembly   | 1 |
| 8  | 364103615   | Power cord             | 1 |
| 9  | 342011635   | Cap                    | 1 |
| 10 | 341031936   | Soap tank              | 1 |
| 11 | 34900365    | Suction hose           | 1 |
| 12 | C1101577-00 | Wheel assembly         | 2 |
| 13 | 331041936   | Lower handle           | 1 |
| 14 | 32222301A   | Nut                    | 4 |
| 15 | 342111936   | Shock pad              | 2 |
| 16 | 341161635   | Foot pad               | 1 |
| 17 | C1101581-00 | Accessory assembly     | 1 |
| 18 | C1101574-00 | Decorative cover       | 1 |
| 19 | 341081936   | Left housing           | 1 |
| 20 | 311601936   | Controller             | 1 |
| 21 | 341091936   | Right housing          | 1 |
| 22 | 311221936   | Switch box             | 1 |
| 23 | 341171936   | Light cover            | 1 |
| 24 | 341013615   | Loudspeaker cover      | 1 |
| 25 | 341403615   | Air cover              | 1 |
| 26 | 332031936   | Water outlet connector | 1 |
| 27 | C1101573-00 | Water inlet connector  | 1 |
| 28 | 311083615   | Motor                  | 1 |
| 29 | 341411936   | Water retaining cover  | 1 |
| 30 | C1101580-00 | Housing assembly       | 1 |