



10663
10665

Single Control Kitchen Faucet


With Pull Down Spray

LIMITED LIFETIME WARRANTY



Before You Begin

Check to make sure you have the following:




Tools and Supplies


You will need the following to install your new faucet:



Adjustable
Wrench




Phillips
Screwdriver




Silicone
Sealant

Faucet Installation


Shut off main water supply before installation.




1 Unscrew screws on lock nut. Remove the lock nut from the faucet body.




2 Install faucet through center hole.




3 Slide rubber washer and metal washer onto shank. Secure shank with lock nut.




4 Connect and tighten the water supply line nuts with wrench.



5 Remove the protective cap from the outlet port prior to pushing the hose adapter onto the same port, you will hear a "click" sound once they are joined.



6 Attach the weight to cover the weight locator label on the spray hose.



7 After installing faucet, remove sprayhead and turn on water to remove any left over debris. Re-assemble sprayhead.


Troubleshooting Guide

Minor problems often can be fixed without a plumber. Before doing any work on the faucet, shut off water supply and close stopper or drain to avoid losing small parts.

Problem	Cause	Solution
Leaks underneath handle.	Locking nut has come loose. O-ring on cartridge is dirty or damaged.	Tighten the locking nut. Clean or replace O-ring.
Hose does not retract.	Metal weight is not installed in the appropriate position.	Reinstall metal weight.
There are leaks from the hose underneath the deck.	Hose and spray head connection may be loose.	Tighten the connection between the spray head and hose.

Replacement Parts

Keep this manual for ordering replacement parts.



- | | | |
|----|------------------------|-------------|
| 1 | Index Button | A66D558 |
| 2 | Metal Handle | A079086 |
| 3 | Handle Trim Cap | A103121 |
| 4 | Adjusting Ring | A104332 |
| 5 | Ceramic Disc Cartridge | A507906N-31 |
| 6 | Cover Plate Assembly | A667003-S |
| 7 | Hose Adapter | A663123N |
| 8 | Pull-Down Spray Head | A568009N |
| 9 | Spray Hose | A515111WCP |
| 10 | Weight | A504103ZN |
| 11 | Mounting Hardware | A603171 |